

PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
876657	1	Main bearing kit	2404	STD D
876658	1	Main bearing kit		U.S=0,25mm
876659	1	Main bearing kit		U.S=0,50mm
	2	Piston kit	2404	
861954	2	Piston ring kit	2404	STD D
861955	2	Piston ring kit		O.S=0,25mm
861956	2	Piston ring kit		OVER SIZE 0,50mm
876669	1	Big end bearing kit	2404	STD D
876670	1	Big end bearing kit		U.S=0,25mm
876671	1	Big end bearing kit		U.S=0,50mm
876688	1	Repair kit, fuel feed pump	171	
875807	1	Impeller kit		(876689)
833550	1	• Impeller		
803730	1	• Screw		
833417	1	• Gasket		
3580900	1	Repair kit, sea water pump		
	1	• Shaft		
181743	2	• Ball bearing		
951086	1	• Lock ring		
951075	2	• Snap ring		
3580903	2	• Sealing ring		
925054	1	• O-ring		
3580906	1	• Cam		
3581371	1	• Screw		
817825	6	• Screw		



PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
3580907	1	• Wear washer		
3580908	1	• Cover		
3580063	1	• O-ring		
876653	1	Gasket kit, reconditioning		
861536	1	• Gasket		
861822	1	• Gasket		
861823	1	• Sealing ring		
861830	1	• O-ring		
861835	1	• Gasket		
861836	1	• Gasket		
861838	1	• Gasket		
11991	4	• Seal		
861851	4	• O-ring		
861860	4	• Valve stem seal		
861865	1	• Gasket		
11992	6	• Gasket		
861887	1	• Gasket		
861888	1	• Gasket		
861897	1	• O-ring		
861907	1	• Gasket		
861909	1	• Gasket		
861917	1	• Gasket		
861997	1	• O-ring		
3580001	1	• Gasket		
3580003	1	• Gasket		
3580025	1	• Gasket		
3580026	1	• Sealing ring		
3580060	1	• Gasket		
3580063	1	• O-ring		
3580069	1	• Spacer		TH = 0,2mm
3580070	1	• Spacer		TH = 0,3mm
3580071	1	• Spacer		TH = 0,4mm
3580072	1	• Spacer		TH=0,5mm
3580075	2	• Gasket		
3580077	2	• Gasket		
3580092	1	• Gasket		
969011	5	• Gasket		
3580111	1	• Gasket		
907132	2	• Gasket		
3580631	2	• Sealing washer		
11992	4	• Gasket		

