



| REF | PART NO. | QTY | DESCRIPTION | SEE SEC. | NOTES |
|-----|----------|-----|-----------------|----------|--|
| 1 | 846022 | 1 | Injection pump | 02C-0150 | SPEC.NO.867715,867716,867718,867723,867830,867933,867934,867935. |
| 2 | 1542171 | 1 | Hub | | |
| 3 | 947314 | 1 | O-ring | IK | |
| 4 | 953046 | 3 | Stud | | |
| 5 | 191172 | 3 | Washer | | |
| 6 | 955782 | 3 | Nut | | |
| 7 | 1542170 | 1 | Fuel pump | | |
| | 273663 | 1 | Repair kit | | |
| 8 | 463392 | 1 | Gasket | IK | |
| 9 | 941907 | 2 | Spring washer | | |
| 10 | 955295 | 2 | Screw | | |
| 11 | 840531 | 1 | Fuel filter | 02C-0100 | |
| 12 | 846789 | 1 | Bracket | | FOR FRONTMOUNTED FUEL FILTER. |
| 13 | 955301 | 2 | Screw | | SEE GROUP 2A |
| 14 | 843075 | 1 | Sleeve | | FOR FRONTMOUNTED FUEL FILTER. |
| | 845589 | 1 | Spacer sleeve | | FOR FRONTMOUNTED FUEL FILTER. |
| 15 | 955317 | 2 | Screw | | |
| 16 | 960148 | 2 | Washer | | |
| 17 | 846017 | 1 | Fuel pipe | | FOR FRONTMOUNTED FUEL FILTER. |
| 18 | 947621 | 4 | Gasket | IK | |
| 19 | 25167 | 2 | Hollow screw | | |
| 20 | 11994 | 4 | Gasket | IK | |
| 21 | 74040 | 1 | Hollow screw | | |
| 22 | 846018 | 1 | Fuel pipe | | FOR FRONTMOUNTED FUEL FILTER. |
| 23 | 845646 | 2 | Fuel hose | | |
| 24 | 11994 | 2 | Gasket | IK | |
| 25 | 74040 | 1 | Hollow screw | | |
| 26 | 404279 | 2 | Clamp | | FOR FRONTMOUNTED FUEL FILTER. |
| 27 | 955272 | 1 | Screw | | FOR FRONTMOUNTED FUEL FILTER. |
| 28 | 946035 | 1 | Lock nut | | FOR FRONTMOUNTED FUEL FILTER. |
| 29 | 840105 | 2 | Rubber sleeve | | |
| 30 | 838583 | 1 | Bracket | | INCLUDED IN INSTALLATION KIT 838978. |
| 31 | 955344 | 2 | Screw | | INCLUDED IN INSTALLATION KIT 838978. |
| 32 | 843122 | 2 | Spacer sleeve | | INCLUDED IN INSTALLATION KIT 838978. |
| 33 | 955317 | 2 | Screw | | |
| 34 | 960148 | 2 | Washer | | |
| 35 | 838587 | 1 | Tube | | INCLUDED IN INSTALLATION KIT 838978. |
| 36 | 25167 | 2 | Hollow screw | | |
| 37 | 947621 | 4 | Gasket | | |
| 38 | 838586 | 1 | Tube | | INCLUDED IN INSTALLATION KIT 838978. |
| 39 | 846780 | 1 | Bracket | | INCLUDED IN INSTALLATION KIT 838978. |
| 40 | 955314 | 1 | Screw | | INCLUDED IN INSTALLATION KIT 838978. |
| 41 | 952624 | 1 | Clamp | | INCLUDED IN INSTALLATION KIT 838978. |
| 42 | 955892 | 1 | Washer | | INCLUDED IN INSTALLATION KIT 838978. |
| 43 | 955271 | 1 | Screw | | INCLUDED IN INSTALLATION KIT 838978. |
| 44 | 829146 | 1 | Pipe connection | | |
| 45 | 954337 | 2 | Nipple | | |
| 46 | 954323 | 2 | Cap nut | | |
| 47 | 11994 | 2 | Gasket | IK | |
| 48 | 74040 | 1 | Hollow screw | | |
| 49 | 845647 | 1 | Tube | | |
| 50 | 844237 | 1 | Hollow screw | | INCLUDED IN FUEL INJECTION PUMP. |

| REF | PART NO. | QTY | DESCRIPTION | SEE SEC. | NOTES |
|-----|----------|-----|----------------|----------|---------------|
| 51 | 11994 | 2 | Gasket | IK | |
| 52 | 74034 | 1 | Hollow screw | | |
| 53 | 957171 | 9 | Gasket | IK | |
| 54 | 1542155 | 4 | Injector | 02C-0200 | |
| | 3803239 | 4 | Injector, exch | | Exchange unit |
| 55 | 1542159 | 4 | Washer | IK | |
| 56 | 1542158 | 4 | Washer | IK | |
| 57 | 1542154 | 4 | Heat shield | | |
| 58 | 1542157 | 4 | Washer | IK | |
| 59 | 1542156 | 4 | Yoke | | |
| 60 | 924068 | 4 | Stud | | |
| 61 | 1542197 | 4 | Washer | | |
| 62 | 955782 | 4 | Nut | | |
| 63 | 1544137 | 1 | Leak-off line | | |
| 64 | 74033 | 3 | Hollow screw | | |
| 65 | 1544151 | 1 | Delivery pipe | | CYL.1 |
| 66 | 1544152 | 1 | Delivery pipe | | CYL.2 |
| 67 | 1544153 | 1 | Delivery pipe | | CYL.3 |
| 68 | 1544154 | 1 | Delivery pipe | | CYL.4 |
| 69 | 470181 | 2 | Clamp | | |
| 70 | 470183 | 1 | Clamp | | |
| 71 | 941905 | 1 | Spring washer | | |
| 72 | 955780 | 1 | Nut | | |