



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	846019	1	Injection pump		SPEC.NO.867711,867712,867720,867927,867928,867929,867939.
				02C-0150	
2	1542171	1	Hub		
3	947314	1	O-ring	IK	
4	953046	3	Stud		
5	191172	3	Washer		
6	955782	3	Nut		
7	1542170	1	Fuel pump		
	273663	1	Repair kit		
8	463392	1	Gasket	IK	
9	941907	2	Spring washer		
10	955295	2	Screw		
11	840531	1	Fuel filter	02C-0100	
12	846789	1	Bracket		FOR FRONTMOUNTED FUEL FILTER.
13	955301	2	Screw		SEE GROUP 2A
14	843075	2	Sleeve		FOR FRONTMOUNTED FUEL FILTER.
15	955317	2	Screw		
16	960148	2	Washer		
17	846017	1	Fuel pipe		FOR FRONTMOUNTED FUEL FILTER.
18	947621	4	Gasket	IK	
19	25167	2	Hollow screw		
20	11994	4	Gasket	IK	
21	74040	1	Hollow screw		
22	846018	1	Fuel pipe		FOR FRONTMOUNTED FUEL FILTER.
23	845646	2	Fuel hose		
24	11994	2	Gasket	IK	
25	74040	1	Hollow screw		
26	404279	2	Clamp		FOR FRONTMOUNTED FUEL FILTER.
27	955272	1	Screw		FOR FRONTMOUNTED FUEL FILTER.
28	946035	1	Lock nut		FOR FRONTMOUNTED FUEL FILTER.
29	840105	2	Rubber sleeve		
30	838583	1	Bracket		INCLUDED IN INSTALLATION KIT 838978.
31	955344	2	Screw		INCLUDED IN INSTALLATION KIT 838978.
32	843122	2	Spacer sleeve		INCLUDED IN INSTALLATION KIT 838978.
33	955317	2	Screw		
34	960148	2	Washer		
35	838587	1	Tube		INCLUDED IN INSTALLATION KIT 838978.
36	25167	2	Hollow screw		
37	947621	4	Gasket		
38	838586	1	Tube		INCLUDED IN INSTALLATION KIT 838978.
39	846780	1	Bracket		INCLUDED IN INSTALLATION KIT 838978.
40	955314	1	Screw		INCLUDED IN INSTALLATION KIT 838978.
41	952624	1	Clamp		INCLUDED IN INSTALLATION KIT 838978.
42	955892	1	Washer		INCLUDED IN INSTALLATION KIT 838978.
43	955271	1	Screw		INCLUDED IN INSTALLATION KIT 838978.
44	829146	1	Pipe connection		
45	954337	2	Nipple		
46	954323	2	Cap nut		
47	11994	2	Gasket	IK	
48	74040	1	Hollow screw		
49	845647	1	Tube		
50	844237	1	Hollow screw		INCLUDED IN FUEL INJECTION PUMP.
51	11994	2	Gasket	IK	

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
52	74034	1	Hollow screw		
53	957171	9	Gasket	IK	
54	1542155	4	Injector	02C-0200	
	3803239	4	Injector, exch		Exchange unit
55	1542159	4	Washer	IK	
56	1542158	4	Washer	IK	
57	1542154	4	Heat shield		
58	1542157	4	Washer	IK	
59	1542156	4	Yoke		
60	924068	4	Stud		
61	1542197	4	Washer		
62	955782	4	Nut		
63	1544137	1	Leak-off line		
64	74033	3	Hollow screw		
65	1544151	1	Delivery pipe		CYL.1
66	1544152	1	Delivery pipe		CYL.2
67	1544153	1	Delivery pipe		CYL.3
68	1544154	1	Delivery pipe		CYL.4
69	470181	2	Clamp		
70	470183	1	Clamp		
71	941905	1	Spring washer		
72	955780	1	Nut		