



3900

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.
1	838040	1	Shaft	
2	951991	1	Spring pin	
3	949303	1	Key	
4	833759	1	Sealing ring	IK
5	181119	1	Ball bearing	
6	838041	1	Spacer ring	
7	838042	1	Spacer ring	
8	963008	1	Lock screw	02A-0550
9	181119	1	Ball bearing	
10	838038	1	Gear	
11	941908	1	Spring washer	
12	955783	1	Nut	
13	955270	4	Screw	02A-1350
14	941906	4	Spring washer	02A-1350
15	838037	1	Gear	02A-1350
16	838145	1	Starter crank	