



3931

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	838289	1	Injector	
	3803230	1	Injector, exch	Exchange unit
2		1	• NOZZLE HOLDER BODY	
3	243467	X	• Adjusting washer	TH = 1,00 MM
	243468	X	• Adjusting washer	TH = 1,05 MM
	243469	X	• Adjusting washer	TH = 1,10 MM
	243470	X	• Adjusting washer	TH = 1,15 MM
	243471	X	• Adjusting washer	TH = 1,20 MM
	243472	X	• Adjusting washer	TH = 1,25 MM
	243473	X	• Adjusting washer	TH = 1,30 MM
	243474	X	• Adjusting washer	TH = 1,35 MM
	243475	X	• Adjusting washer	TH = 1,40 MM
	243476	X	• Adjusting washer	TH = 1,45 MM
	243477	X	• Adjusting washer	TH = 1,50 MM
	243478	X	• Adjusting washer	TH = 1,55 MM
	243479	X	• Adjusting washer	TH = 1,60 MM
	243480	X	• Adjusting washer	TH = 1,65 MM
	243481	X	• Adjusting washer	TH = 1,70 MM
	243482	X	• Adjusting washer	TH = 1,75 MM
	243483	X	• Adjusting washer	TH = 1,80 MM
	243484	X	• Washer	TH = 1,85 MM
	243485	X	• Adjusting washer	TH = 1,90 MM
	243486	X	• Adjusting washer	TH = 1,95 MM
4	840835	1	• Compression spring	
5	243465	1	• Push rod	
6	840836	1	• Washer	
7	840837	2	• Pin	
8	838287	1	• Nozzle	
9	243489	1	• Nut	
10	190990	2	• Gasket	
	466037	1	• Washer	
11	243487	1	• Screw	