



5167

| REF | PART NO. | QTY | DESCRIPTION | | NOTES |
|-----|----------|-----|----------------------|----|-------------------------------------|
| 1 | 471036 | 1 | Bearing housing | | |
| 2 | 424580 | 1 | Sealing ring | IK | |
| 3 | 422073 | 1 | Shaft | | |
| 4 | 11013 | 1 | Ball bearing | | |
| 5 | 469363 | 1 | Stop ring | | |
| 6 | 469364 | 1 | Gear | | |
| 7 | 421083 | 1 | Stop ring | | REPLACED BY 1EA 469363, 1EA 469364. |
| 8 | | | SPACER SLEEVE | | |
| 9 | 181577 | 1 | Ball bearing | | |
| 10 | 423074 | 1 | Washer | | |
| 11 | 940100 | 6 | Screw | | |
| 12 | 421415 | 3 | Lock washer | | |
| 13 | 950586 | 1 | Pin | | |
| 14 | 422329 | 1 | Woodruff key | | |
| 15 | 421079 | 1 | Gear | | SEE GROUP 2A |
| 16 | 102056 | 3 | Screw | | |
| 17 | 467052 | 1 | Lock washer | | |
| 18 | 467055 | 3 | Washer | | |
| 19 | 423123 | 1 | Sealing ring | | |
| 20 | 955525 | 4 | Screw | | L = 25 MM |
| | 955527 | 1 | Screw | | L = 57 MM |
| 21 | 941907 | 5 | Spring washer | | |
| 22 | 823474 | 1 | Bearing housing | | |
| 23 | 191776 | 2 | · Bushing | | |
| 24 | 422125 | 1 | Axle shaft | | |
| 25 | 943821 | 1 | Ring | IK | |
| 26 | 422130 | 1 | Gasket | | |
| 27 | 953224 | 2 | Stud | | |
| 28 | 955825 | 2 | Nut | | |
| 29 | 941906 | 2 | Spring washer | | |
| 30 | 422643 | 1 | Cover | | |
| 31 | 422184 | 1 | Companion flange | | |
| 32 | 421188 | 1 | Intermediate section | | |
| 33 | 422461 | 1 | Companion flange | | |
| 34 | 417512 | 6 | Dog clutch disc | | |
| 35 | 955675 | 2 | Screw | | |
| 36 | 422469 | 2 | Screw | | |
| 37 | 955676 | 4 | Screw | | |
| 38 | 422187 | 8 | Nut | | |
| 39 | 417514 | 8 | Washer | | |
| 40 | 940097 | 2 | Washer | | |
| 41 | 940160 | 1 | Screw | | |
| 42 | 955896 | 1 | Washer | | |
| 43 | 836996 | 1 | Pump coupling guard | | |
| 44 | 955894 | 1 | Washer | | |
| 45 | | 1 | TACHOMETER SENSOR | | SEE GROUP 3. |