



2577

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	242643	1	Injection pump		
2	242872	1	· Centrifugal governor		
				02C-1000	
3	242034	1	· Feed pump		
				02C-1300	
4	242030	1	· Housing		
5	242465	3	· Nut		
6	941906	3	· Spring washer		
7	242461	3			
8	236647	6	· Lock ring		
9	242541	3	· Bolt		
10	242032	3	· Spacer washer		
11	236906	6	· Retainer		
12	236761	6	· Gasket		
13	78357	6	· O-ring		
14	242542	6	· Plug		
15	242682	6	· Spring		
16	236449	6	· Gasket		
17	236903	6	· Delivery valve		
18	242681	6	· Pump element		
19	115300	6	· Lock screw		
20	236648	6	· Gear segment		
21	115070	6	· Screw		
22	78359	6	· Control sleeve		
23	236899	1	· Fitting		
24	242457	1	· Washer		
25	180748	1	· Plug		
26	236641	1	· Gasket		
27	236438	1	· Fitting		
28	180039	1	· Banjo nipple		
29	236641	1	· Gasket		
30	78415	2	· Screw		
31	236637	2	· Gasket		
32	236394	1	· Bushing		
33	78333	2	· Bushing		
34	236764	1	· Control shaft		
35	242518	1	· Screw		
36	941906	1	· Spring washer		
37	236902	1	· Bearing shield		
38	78349	1	· Gasket		
39	955272	4	· Screw		
40	941906	4	· Spring washer		
41	19946	1	· Sealing ring		
42	236460	X	· Adjusting washer		TH = 0,15 MM
	236461	X	· Adjusting washer		TH = 0,20 MM
	236462	X	· Adjusting washer		TH = 0,25 MM
	236463	X	· Adjusting washer		TH = 0,91 MM
43	18524	2	· Roller bearing		
44	242033	1	· Camshaft		
45	910115	1	· Key		
46	941911	1	· Spring washer		
47	242464	1			
48	78362	6	· Spring disc		
49	78361	6	· Spring		
50	236650	6	· Spring disc		
51	78434	X	· Adjusting washer		TH = 0,3 MM
	78433	X	· Adjusting washer		TH = 0,4 MM
	78432	X	· Adjusting washer		TH = 0,5 MM
	78435	X	· Adjusting washer		TH = 0,6 MM
	242803	X	· Washer		TH = 0,7 MM
	78425	X	· Adjusting washer		TH = 0,8 MM
	78426	X	· Adjusting washer		TH = 0,9 MM
	78427	X	· Adjusting washer		TH = 1,0 MM
	78428	X	· Adjusting washer		TH = 1,1 MM

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
51	78429	X	· Adjusting washer		TH = 1,2 MM
	78430	X	· Adjusting washer		TH = 1,3 MM
	78431	X	· Adjusting washer		TH = 1,4 MM
52	236466	6	· Tappet		
53	78366	6	· · Pin		
54	78367	6	· · Bushing		
55	236456	6	· · Roller		
56	236455	6			
57	236467	6	· Adjusting screw		
58	242230	1	· Fitting		
59	957178	1	· Gasket		
60	236439	1	· Plug		
61	236641	1	· Gasket		
62	960630	1	· Plug		
63	957178	1	· Gasket		
64	78414	1	· Gasket		
65	130024	4			
66	242465	4	· Nut		
67	941906	4	· Spring washer		
68	78337	1	· Cover		
69	78338	1	· Gasket		
70	956090	14	· Screw		
71	242427	1			
72	78341	1	· Gasket		
73	130026	3	· Screw		
74	42780	3	· Gasket		
75	78340	3	· Nut		
76	960630	1	· Plug		
77	242418	1	· Setting indicator		