



5290

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	843512	1	Injection pump		
2	243773	1			
3	243083	1	· Feed pump	02C-1000	
				02C-1350	
4		1	· HOUSING		
5	239982	6	· Tappet		
6	240779	6	· · Bolt		
7	240780	6	· · Bushing		
8	240781	6	· · Roller		
9	238379	6	· · Plate		
10	244685	6	· Spring disc		
11	244065	6	· Spring		
12	239984	6	· Spring disc		
13	240782	6	· Control sleeve		
14	239991	6	· Cover		
15	241677	6	· Washer		
16	239990	6	· Lock ring		
17	240003	6	· Spacer ring		
18	240002	6	· O-ring		
19	240424	X	· Gasket		TH = 0.15 MM
	240004	X	· Gasket		TH = 0.40 MM
	240005	X	· Gasket		TH = 0.50 MM
	240006	X	· Gasket		TH = 0.60 MM
	240007	X	· Gasket		TH = 0.70 MM
	240008	X	· Gasket		TH = 0.80 MM
20	243741	6	· Bushing		
21	240422	12	· O-ring		
22	240808	6	· Pump element		
23	240423	6	· Delivery valve		
24	239993	6	· Gasket		
25	243742	6	· Delivery valve retai		
26	243743	12	· Washer		
27	240969	6	· Spring		
28	240001	6	· Gasket		
29	240010	12	· Screw		
30	941908	12	· Spring washer		
31	955783	12	· Nut		
32	240011	1	· Cover		
33	956209	2	· Screw		
34	18891	2	· Lock washer		
35	240907	1	· Control rod		
36	240014	2	· Guide sleeve		
37	244008	1	· Lock pin		
38	240015	1	· Bushing		
39	240971	6	· Plug		
40	240972	X	· Washer		TH = 0.2 MM
	240973	X	· Washer		TH = 0.5 MM
41	837735	6	· Plug		
42	18836	6	· Gasket		
43	243263	1	· Plug		
44	240017	1	· Gasket		
45	240789	1	· Camshaft		
46	240426	1	· Bearing		
47	240427	2	· Screw		
48	941906	2	· Spring washer		
49	240023	1	· Roller bearing		
50	240022	1	· Sealing ring		
51	243299	1	· O-ring		
52	240024	X	· Adjusting washer		TH = 0.10 MM
	240025	X	· Adjusting washer		TH = 0.12 MM
	240026	X	· Adjusting washer		TH = 0.14 MM
	240027	X	· Adjusting washer		TH = 0.16 MM
	240028	X	· Adjusting washer		TH = 0.18 MM

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
52	240029	X	· Adjusting washer		TH = 0.30 MM
	240030	X	· Adjusting washer		TH = 0.50 MM
53	240021	1	· Cover		
54	956094	4	· Screw		
55	941906	4	· Spring washer		
56	955806	1	· Nut		
57	941913	1	· Spring washer		
58	35168	1	· Key		
59	240023	1	· Roller bearing		
60	240032	1	· Ring		
61	240033	X	· Adjusting washer		TH = 1.2 MM
	240034	X	· Adjusting washer		TH = 1.5 MM
	240035	X	· Adjusting washer		TH = 1.8 MM
	240036	X	· Adjusting washer		TH = 2.0 MM
62	240947	1	· Cover		
63	240948	1	· Gasket		
64	956205	12	· Screw		
65	239896	1	· Gasket		
66	130673	3	· Stud		
67	955781	3	· Nut		
68	941906	3	· Spring washer		
69	241647	1	· Setting indicator		
70	955268	2	· Screw		
71	941906	2	· Spring washer		