



5937

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	466549	2	Cylinder head	
	3803035	2	Cylinder head, exch	Exchange unit
2	421011	6	· Valve seat	STD D
	421316	6	· Valve seat	0,20 MM O.S
3	466266	6	· Valve seat	STD D
	466307	6	· Valve seat	0,20 MM O.S
4	466386	12	· Valve guide	
5	466405	6	· Rubber ring	IK
6	466403	6	· Sleeve	
7	192426	2	· Plug	
8	467367	4	· Plug	
9	469328	4	· Gasket	IK
10	466230	4	· Plug	
11	420166	4	· Gasket	IK
12	466420	6	· Steel ring	
13	466922	6	· O-ring	
14	421016	6	Inlet valve	
15	421208	6	Exhaust valve	
16	421374	12	Valve spring	
18	421295	12	Washer	
19	402418	24	Valve collet	
20	469365	12	Valve cap	
21	469456	12	Protecting ring	IK
22	421416	6	Bearing bracket	
23	420270	4	Stud	
24	955540	8	Screw	
25	942336	8	Spring washer	
26	421019	2	Shaft	
27	946778	4	· Cap plug	
28	422063	12	Rocker arm	
29	422066	12	· Bushing	
30	423058	12	· Ball stud	
31	940175	12	· Nut	
32	421173	4	Spring	
33	421172	4	Spring	
34	914459	4	Lock ring	
35	275525	2	Gasket kit	
36	422414	12	· Sealing ring	IK D = 32 MM
	466421	16	· Sealing ring	IK D = 16 MM
	422413	2	· Sealing ring	IK D = 11 MM
37	421218	20	Screw	L = 168 MM
38	466764	6	Screw	L = 118 MM
39	421063	1	Cover	
40	421065	1	Cover	
41	424341	4	Cap nut	
42	469846	4	Sealing ring	IK
43	914449	4	Lock ring	
44	421066	2	Gasket	IK
45	420292	1	Oil filler cap	
46	940096	1	Gasket	IK
47	949020	4	Pin	
48	469455	6	Sealing ring	