



17835

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	849758	1	Injection pump		RQV GOVERNOR
	3803767	1	Injection pump, exch	1144	Exchange unit
1	849836	1	Injection pump, AUX		RQ GOVERNOR
	3803768	1	Injection pump, exch	1145	Exchange unit
	865277	1	Injection pump, AUX		GAC GOVERNOR. Electronic speed control for auxiliary engines.
	3803776	1	Injection pump, exch	1178	Exchange unit
2	11996	1	Gasket		
3	479775	1	Overflow valve		(35096)
4	477173	1	Pressure equalizer		
5	969011	1	Gasket		
6	965189	4	Flange screw		
7	190509	3	Washer		
8	941908	1	Spring washer		
9		1	Bracketmanual speed control		SEE GROUP 27
10	862997	1	Oil feed pipe		Ferrule and nut is not included.
11	1543721	2	Bracket		
12	952623	1	Clamp		
13	956092	1	Screw		
14	48634	1	Hollow screw		
15	947281	2	Gasket		
16	191936	1	T-pipe, cylinder block		
17	954356	2	Cap nut		
18	954364	1	Fitting		
19	943006	1	Plug		
20	862996	1	Oil return pipe		SN-XXXXXXXXXX/9438. Replaced by 3826169.
21	952625	1	Clamp		SN-XXXXXXXXXX/9438
22	25167	1	Hollow screw		SN-XXXXXXXXXX/9438
23	969011	2	Gasket		SN-XXXXXXXXXX/9438
24	3826169	1	Oil return pipe		SNXXXXXXXXXXXX/9439-
25	952623	1	Clamp		SNXXXXXXXXXXXX/9439-
26	48634	1	Hollow screw		SNXXXXXXXXXXXX/9439-
27	947281	2	Gasket		SNXXXXXXXXXXXX/9439-
28	25167	1	Hollow screw		
29	969011	2	Gasket		
30	956092	1	Screw		
31	417588	1	Guide sleeve		
32	945460	X	Plastic pipe		L=45mm,(924079)
33	954364	2	Fitting		
34	954356	2	Cap nut		
35	944717	2	Sleeve		
36	969299	1	Hollow screw		
37	11994	2	Gasket		
38	954385	1	Elbow nipple		
39	180759	1	Plug, AUX		
40	945417	1	Nipple		
41	3830312	2	Fuel hose		
42	16496	1	Hollow screw		
43	25167	1	Hollow screw		
44	969011	4	Gasket		
45	22753	2	Nipple		
46		1	Leak-off line	2166	
47		1	Hollow screw	2166	
48		2	Gasket	2166	
49	3825969	1	Fuel pipe		
50	849887	1	Fuel pipe		
51	404279	2	Clamp		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
52	956094	1	Screw		
53	955892	1	Washer		
54	955781	1	Nut		
55	25167	4	Hollow screw		
56	969011	8	Gasket		
57	862189	1	Bracket		
58	946173	2	Flange screw		
59	955513	1	Screw		
60	941907	1	Spring washer		
	955894	1	Washer		
61	822791	2	Spacer sleeve, pump coupling guard		
62		1	Fuel filter		
				3879	
63	965185	2	Flange screw		
64	971095	2	Nut		