



16392

REF	PART NO.	QTY	DESCRIPTION	NOTES
1		1	Flywheel housing	
2	11032061	1	· Flywheel housing	
3	1543896	1	· Sealing ring	
4	4772168	2	Cover	
	4772169	1	Cover, impulse sensor	
5	946934	4	Flange screw	
6	4804167	2	Gasket	
7	1543173	1	Setting indicator	
8	971005	2	Screw	M14x80mm
9	971003	10	Screw	M14x70mm
10	971008	2	Screw	M14x110mm
11	955899	14	Washer	
12	941911	14	Spring washer	
13	965181	1	Screw	M8x70mm
15	180761	1	Plug	
16	11996	1	Gasket	
17	849135	1	Cover	
18	959253	3	Allen head screw	
19	968145	1	Plug	3/8NPTF
20	467367	1	Plug	
21	1161231	X	Sealant	304ml
	1161277	X	Sealant	10g
22	849466	1	Breather pipe	SO
23	421158	1	Sealing ring	