



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	3825514	1	Oil pan		EARLY TYPE
	3829432	1	Oil pan		LATE TYPE
2	3827274	1	Gasket		(864775)
3	947760	44	Flange screw		
4	820917	44	Spacer sleeve		FOR 3825514
5	844605	1	Oil dipstick		
6	3825065	1	Tube		
6A	949175	1	Magnetic plug		
7	957187	2	Washer		
8	866936	1	Oil filler pipe		
9	1275403	1	Oil filler cap		
9A	1275379	1	· Gasket		
10	949175	1	Magnetic plug		
10A	949329	1	Gasket		
11	946173	5	Flange screw		
12	843584	1	Sealing ring		
13	3825477	1	Suction pipe		SNXXXXXXXXXX/27111-
13A	864703	1	Suction pipe		SN-XXXXXXXXXX/27110
14	864702	1	Bracket		SN-XXXXXXXXXX/27110
15	946440	2	Flange screw, reinforc. frame		SNXXXXXXXXXX/27111-
15	946440	2	Flange screw		SN-XXXXXXXXXX/27110
16	965180	2	Flange screw		
17	1543579	2	Sealing ring		
18	864968	1	Flange		
19	949722	1	O-ring		
20		1	Pipeincl nut and ferrule		EARLY TYPE. Replaced by 1ea pressure oil 382186 and 2ea sealing ring 1543578.
	3826186	1	Oil feed pipe, incl nut and ferrule		LATE TYPE
21	1543578	1	Sealing ring		EARLY TYPE
	1543578	2	Sealing ring		LATE TYPE
22	965186	4	Flange screw		
23	1556730	1	Oil pump	404	
24	945444	2	Flange screw		
25	1543608	1	Cover		
26	949659	1	O-ring		
27	1543630	1	Spring		
28	1543610	1	Peg		
29	1543964	1	Valve seat		
30	1556430	6	Jet, piston cooling		
31	955981	6	· O-ring		
32	1556434	6	Stud		
33	948645	6	Lock nut		