



REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3825903	1	Heat exchanger housi	SN-1101053650/XXXXX. For replacement of heat exchanger 866609, replace even coolant pipe 866580 and pipe connection 866578 to cover 3825918.
1	3826858	1	Heat exchanger housi	SN1101053651/XXXXX-
2	949918	2	Drain cock	
3	849031	1	Cover	
4	842137	1	Gasket	(862022)
5	864311	1	Retainer	
5A	864382	1	Coolant pipe, intercooler	
5B	864559	1	Clamp	
5C	976944	1	Washer	
5D	944926	1	Flange screw	
6	863209	2	Sealing ring	
7	946173	8	Flange screw	
8	866772	1	Coolant pipe	
9	849401	2	Clamp	
10	965178	2	Flange screw	
11	843584	1	Sealing ring	
12	823661	2	Zinc anod	
13	836169	2	Gasket	
14	823662	2	Plug	
15	955373	2	Screw	
16	941912	2	Spring washer	
17	946472	3	Screw	
18	421158	1	Sealing ring	
19	955977	2	Rubber ring	
20	3825961	1	Heat exchanger eleme	
21	925276	1	O-ring, heat exchanger insert	
22	925278	3	O-ring	
23	950529	2	Pin	
24	849032	1	Cover	
25	849053	1	Bracket	
26	946472	4	Screw	
27	965190	4	Screw	
28	925079	1	O-ring	
29	866577	1	Coolant pipe	
30	3826974	1	Connector	(866563)
31	863210	2	Sealing ring	
32	925078	1	O-ring, therm. housing	
33	945444	2	Flange screw, therm. housing	
34	976944	2	Washer, therm. housing	(966674)
35	866566	1	Flange, therm. housing	