



5170

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	844459	1	Injector	
2		1	• NOZZLE HOLDER	
3	74033	1	• Hollow screw	
4	947620	2	• Gasket	(233321)
5	844294	1	• Gasket	
6	844295	1	• O-ring	
7	244443	1	• Fitting	
8	244444	1	• Spring	
9	244445	1	• Push rod	
10	844339	2	• Locating pin	
11	244447	2	• Pin	
12	244537	1	• Washer	
13	844299	1	• Adjusting washer	TH = 1,000 MM
	846960	1	• Adjusting washer	(844300) TH = 1,025 MM
	846945	1	• Adjusting washer	(844301) TH = 1,050 MM
	846961	1	• Adjusting washer	(844302) TH = 1,075 MM
	844303	1	• Adjusting washer	TH = 1,100 MM
	6212418	1	• Adjusting washer	TH = 1,125 MM (844341)
	846947	1	• Adjusting washer	(844342) TH = 1,150 MM
	844343	1	• Adjusting washer	TH = 1,175 MM
	844304	1	• Adjusting washer	TH = 1,200 MM
	6212417	1	• Adjusting washer	TH = 1,225 MM (844305)
	846948	1	• Adjusting washer	(844306) TH = 1,250 MM
	846964	1	• Adjusting washer	TH = 1,275 MM (844307)
	844308	1	• Adjusting washer	TH = 1,300 MM
	846965	1	• Adjusting washer	(844309) TH = 1,325 MM
	846950	1	• Adjusting washer	(844310) TH = 1,350 MM
	844311	1	• Adjusting washer	TH = 1,375 MM
	844312	1	• Adjusting washer	TH = 1,400 MM
	6212393	1	• Adjusting washer	(844313) TH = 1,425 MM
	846952	1	• Adjusting washer	(844314) TH = 1,450 MM
	844315	1	• Adjusting washer	TH = 1,475 MM
	844316	1	• Adjusting washer	TH = 1,500 MM
	844317	1	• Adjusting washer	TH = 1,525 MM
	846954	1	• Adjusting washer	TH = 1,550 MM (844318)
	846969	1	• Adjusting washer	TH = 1,575 MM (844319)
	844320	1	• Adjusting washer	TH = 1,600 MM
	846970	1	• Adjusting washer	(844321) TH = 1,625 MM
	846956	1	• Adjusting washer	TH = 1,650 MM (844322)
	844323	1	• Adjusting washer	TH = 1,675 MM
	844324	1	• Adjusting washer	TH = 1,700 MM
	844325	1	• Adjusting washer	TH = 1,725 MM
	846957	1	• Adjusting washer	(844326) TH = 1,750 MM
	844327	1	• Adjusting washer	TH = 1,775 MM
	844328	1	• Adjusting washer	TH = 1,800 MM
	844329	1	• Adjusting washer	TH = 1,825 MM
	846958	1	• Adjusting washer	(844330) TH = 1,850 MM
	846977	1	• Adjusting washer	TH = 1,875 MM (844331)
	844332	1	• Adjusting washer	TH = 1,900 MM
	846978	1	• Adjusting washer	TH = 1,925 MM (844333)
	846959	1	• Adjusting washer	(844334) TH = 1,950 MM
	846980	1	• Adjusting washer	(844335) TH = 1,975 MM
14	844460	1	• Nozzle	
15	244448	1	• Cap nut	