



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	466530	1	Oil pump		
				02A-1900	
2	421404	1	Baffle		
3	955538	4	Screw		
4	925060	1	O-ring	IK	
5	466880	1	Flange		
6	959794	2	Screw		
7	941907	2	Spring washer		
8	925076	1	Ring		
9	466882	1	Tube		
10	466906	2	Fitting		
11	844273	1	Delivery pipe		
12	466905	2	Fitting		
13	942402	2	Flange screw		
14	941907	2	Spring washer		
15	843666	1	Bracket		
16	949747	1	Clamp		
17	949746	1	Clamp		
18	942402	2	Flange screw		
19	843558	1	Tube		
20	949658	1	O-ring	IK	
21	955531	2	Screw		
22	941907	2	Spring washer		
23	843559	1	Bracket		
24	955523	3	Screw		
25	843560	1	Oil pan		
26	424601	1	Gasket	IK	
27	955525	36	Screw		
28	941907	36	Spring washer		
29	837964	1	Gasket		
30	842006	1	Flange		
31	940094	2	Screw		
32	941906	2	Spring washer		
33	957185	1	Gasket		
34	192538	1	Magnetic plug		
35	844605	1	Oil dipstick		
36	955982	1	O-ring		
37	837964	1	Gasket		
38	847218	1	Tube		
39	940094	2	Screw		
40	941906	2	Spring washer		
41	469468	1	Valve seat		
42	469846	1	Sealing ring		
43	471085	1	Valve		
44	466445	1	Spring		
45	470291	1	Spring		
46	949658	1	O-ring		
47	469465	1	Cover		
48	955512	2	Screw		
49	941906	2	Spring washer		
50	466751	1	Housing		
51	949656	2	O-ring		
52	940115	2	Screw		
53	942336	2	Spring washer		
54	471387	2	Sealing ring		SEE GROUP 2B
55	471386	2	Tube		
56	968145	2	Plug		
57		1	OIL COOLER AND INSTALLATION COMPONENT		SEE GROUP 2B
58	843874	1	Housing		
59	949656	2	O-ring		
60	471034	1	Oil filter		
61	940115	3	Screw		
62	942336	3	Spring washer		