



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	847319	1	Injection pump		
				02C-0925	
2	417588	1	Guide sleeve		SEE GROUP 2B
3	940156	4	Screw		
4	190509	4	Washer		
5	942336	4	Spring washer		
6		1	DRIVE DEVICE FOR FUEL INJECTION PUMP	02C-0600	
7	471172	1	Filter housing		
				02C-1675	
8	466987	2	Fuel filter		
				02C-1675	
9	843974	1	Bracket		SEE GROUP 2B
10	955536	2	Screw		
11	942336	4	Spring washer		
12	955827	2	Nut		
13	960630	3	Plug		
14	957178	3	Gasket		
15	843651	1	Delivery pipe		CYL NO. 1
16	843652	1	Delivery pipe		CYL NO. 2
17	843653	1	Delivery pipe		CYL NO. 3
18	843654	1	Delivery pipe		CYL NO. 4
19	843655	1	Delivery pipe		CYL NO. 5
20	843656	1	Delivery pipe		CYL NO. 6
21	844286	6	Injector		
				02C-1550	
22	469797	6	Yoke		
23	466400	6	Stud		
24	961992	6	Nut		
25	466401	6	Pin		
26	466896	1	Leak-off pipe		
27	843657	1	Leak-off pipe		
28	74034	1	Hollow screw		
29	946729	3	Gasket		
30	74033	5	Hollow screw		INCLUDED IN FUEL INJECTOR.
31	957178	3	Gasket	IK	
32	35096	1	Overflow valve		
33	16496	1	Hollow screw		
34	947620	12	Gasket		
35	240579	1	Hollow screw		
36	845372	2	Fuel hose		
37	22753	2	Nipple		
38	25167	1	Hollow screw		
39	957178	2	Gasket	IK	
40	843649	1	Fuel pipe		
41	843648	1	Fuel pipe		
42	25167	3	Hollow screw		
43	944679	1	Hollow screw		
44	957178	8	Gasket	IK	
45	240664	1	Screw		
46	25534	1	Gasket		
47	846927	1	Oil feed pipe		
48	191936	1	T-pipe		
49	954364	1	Fitting		
50	954356	1	Cap nut		
51	48634	1	Hollow screw		
52	957173	2	Gasket	IK	
53	843975	1	Oil return pipe		
54	25167	1	Hollow screw		
55	942007	1	Hollow screw		
56	18671	3	Gasket	IK	
57	11998	1	Gasket	IK	
58	843659	1	Tube		
59	949554	1	Nipple		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
60	954357	1	Cap nut		
61	954365	1	Fitting		
62	74040	1	Hollow screw		
63	11994	2	Gasket	IK	
64	942400	1	Clamp		
65	466398	1	Pressure equalizer		
66	18671	1	Gasket	IK	
67	422525	1	Attaching lug		
68	121563	1	Clamp		
69	845073	2	Clamp		FOR 3 PIPES
	845072	3	Clamp		FOR 2 PIPES.
70	965535	1	Bracket		SEE GROUP 2B
71	950045	1	Screw		