

DESCRIPTION	SEE SEC.	NOTES
Alternator	4478	TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Alternator, Side Mounted	3598	TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Alternator, High Mounting	3998	TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Alternator 14V 130A, Components	594	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Alternator 28V 60A, Components: 873771	6126	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Alternator 14V 60A, Components: 873770	4939	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Alternator 28V 100A, Components	596	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Alternator Cover	5471	TAMD74A-A, TAMD74A-B
Charging Distributor	258	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Charging Distributor: 858841	365	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Charging Distributor: 859499	365B	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Charging Distributor: 873120	365C	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Starter Motor: 14V	4480	TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Starter Motor: 28V	4480B	TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Starter Motor/ Hydraulic Starter (AUX): AUX	4996	TAMD74A
Starter Motor/ Air Starter and Installation Components, (Aux): AUX	4847	TAMD74A
Starter Motor, Components	440	TAMD75P-A
Alarm Panel, Classifiable: TAMD 71B (AUX), TAMD74A AUX	3656	TAMD74A-A, TAMD74A-B
Electrical Box for Single Electrical System: 838419	1164	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Electrical Box for Single Electrical System: 846904	1164B	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Electrical Box, Classifiable: TAMD74A AUX	4981	TAMD74A-A, TAMD74A-B
Electrical Box, Classifiable	21583	TAMD74A-A, TAMD74A-B
Electronic Unit, CU-2500: CU 2500 P	5006	TAMD74A-A, TAMD74A-B
Electronic Unit, CU-2500: CU 2500 A	5006B	TAMD74A-A, TAMD74A-B
Electronic Unit CU2500 and DCU305 R2: CU 2500 A	21574	TAMD74A
Electronic Unit CU2500 and DCU305 R2: DCU 305 R2	21574B	TAMD74A
Supervising Equipment. Classifiable: TAMD74A AUX	4985	TAMD74A-A, TAMD74A-B
Contacts and Sensors: TAMD74A AUX	4728	TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Sensors, Classifiable Engine: TAMD74A AUX	5466	TAMD74A-A, TAMD74A-B

DESCRIPTION	SEE SEC.	NOTES
Leakage Switch for Fuel. Classifiable: TAMD71B (AUX), TAMD74A (AUX)	3659	TAMD74A
Electrical System	4481	TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Instrument Panel 12V, Earlier Production: 864045	1651	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Instrument Panel 12V	787	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Instrument Panel 24V: TAMD74A AUX	5279	TAMD74A
Instrument Panel 24V	2464	TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Instrument Panel for Dual Station, 12V	802	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Instrument Panel for Dual Station, 24V	825	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Extra Panel 12V, Turbo, Oil Pressure, Rev. Gear	5463	TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Instrument Panel. Classifiable	4495	TAMD74A-A, TAMD74A-B
Extra Panel 24V, Turbo Pressure, Oil Pressure Reverse Gear: 846803, 849939	2459	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Extra Panel 24V, Turbo Pressure, Oil Pressure Reverse Gear: 864050	2459B	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Extra Panel 24V, Turbo Pressure, Oil Pressure Reverse Gear: 864053	2459C	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Extra Instrument Panel, Classifiable	2297	TAMD74A-A, TAMD74A-B
Extra Panel 12V, Turbo, Oil Pressure, Rev. Gear	4749	TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Instrument Panel for Alternative Control Station. Classifiable	2298	TAMD74A-A, TAMD74A-B
Instr. Panel for Twin Engine Install. Mirror-Invert	366	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Instruments for Separate Mounting: 12V	775	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Instruments for Separate Mounting: 24V	775B	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Monitoring Panel: A	4372	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Monitoring Panel: B	4372B	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Monitoring Panel for Single and Two Or More Stations: A	3580	TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Monitoring Panel for Single and Two Or More Stations: B	3580B	TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Monitoring Panel for Single and Two Or More Stations: C	3580C	TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Alarm Panel 24V and Relay Card for Parallel Indication. Classifiable	5460	TAMD74A-A, TAMD74A-B

DESCRIPTION	SEE SEC.	NOTES
Rudder Indicator Kit for Reverse Gear	252	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Alarm Panel	280	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Tank Meter Kit for Fuel and Fresh Water, 24V: FUEL	1175	TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Tank Meter Kit for Fuel and Fresh Water, 24V: FRESH WATER	1175B	TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Tank Meter Kit for Fuel: 12V	4724	TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Tank Meter Kit for Fuel: 24V	4724B	TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Main Battery Switch	260	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Electrical Materials	1963	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Electrical Materials	1964	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Electrical Materials	1965	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A
Electrical Materials	4415	TAMD74A, TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74C-B, TAMD74L-A, TAMD74L-B, TAMD74P-A, TAMD74P-B, TAMD75P-A