



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	1545119	1	Oil pump		
				02A-1275	
2	190529	2	Lock washer		
3	955538	4	Screw		
4	824156	1	Oil pump screen		
5		1	· STRAINER		
6		1	· LOCK RING		
7	949658	1	O-ring		
8	955530	2	Screw		
9	941907	2	Spring washer		
10	1545270	1	Oil feed pipe		
11	1545272	1	Flange		
12	1545271	1	Sealing ring		
13	955531	2	Screw		
14	941907	2	Spring washer		
15	466907	1	Fitting		
16	846641	1	Tube		
17	940135	2	Screw		
18	941907	2	Spring washer		
19	949658	1	O-ring		
20	896682	1	Bracket		
21	942402	4	Flange screw		
22	1545011	1	Bracket		
23	955523	2	Screw		
24	941907	2	Spring washer		
25	1545203	2	Bracket		
26	943121	1	Clamp		
	945557	1	Clamp		
27	940117	4	Screw		
28	1545269	4	Sleeve		
29	955825	4	Nut		
30	960140	4	Washer		
31	469846	1	Sealing ring		
32	469468	1	Valve seat		
32A	471706	1	Reducing valve		LATE TYPE
33	471085	1	Valve		
34	469332	1	Spring		
35	470291	1	Spring		
36	949658	1	O-ring		
37	469465	1	Cover		
	471752	1	Cover		LATE TYPE
38	955512	2	Screw		
39	949607	2	Spring washer		
40	896775	1	Tube		
41	862602	1	Gasket		
42	955525	2	Screw		
43	941907	2	Spring washer		
44	863100	1	Oil pan		
45	968216	1	Plug		
46	1545696	1	Gasket		
47	956570	41	Screw		
48	941907	41	Spring washer		
49	821101	1	Oil dipstick		
50	801480	1	Sleeve		
51	802057	1	Inspection lid		
52	800877	2	Inspection lid		
53	862597	3	Gasket		
54	956569	36	Screw		
55	11992	36	Gasket		
56		1	OIL SUMP PUMP AND INSTALLATION COMPONENTS	02A-1575	
57		1	OIL FILTER AND INSTALLATION COMPONENTS	02A-1325	
		1	OIL FILTER AND INSTALLATION COMPONENTS	02A-1335	

--

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
57					
58		1	OIL AND FUEL SUPERVISION		SEE GROUP 3

