



7558

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	846682	1	Injection pump		REPL BY 847768
2	846377	1	· Actuator, GOVERNOR INSTALLATION COMPONENTS		SEE GROUP 2D
3	243083	1	· Feed pump		
				02C-0650	
4		1	· PUMP HOUSING		
5	244404	6	· Push rod		
6	240779	6	· · Bolt		
7	240780	6	· · Bushing		
8	846577	6	· · Bearing		
9	238379	6	· · Plate		
10	244685	6	· Spring disc		
11	244731	6	· Spring		
12	239984	6	· Spring disc		
13	240782	6	· Control sleeve		
14	239991	6	· Cover		
15	844988	1	· Plug		
16	848299	6	· Lock ring	IK	
17	241677	6	· Washer	IK	
18	846937	6	· O-ring		
19	844990	X	· Adjusting washer		TH = 0,40 MM
	847428	X	· Adjusting washer		TH = 0,45 MM
	844991	X	· Adjusting washer		TH = 0,50 MM
	847429	X	· Adjusting washer		TH = 0,60 MM
	844992	X	· Adjusting washer		TH = 0,70 MM
	844993	X	· Adjusting washer		TH = 0,80 MM
	847430	X	· Adjusting washer		TH = 0,85 MM
	845238	X	· Adjusting washer		TH = 0,90 MM
	844994	X	· Adjusting washer		TH = 1,00 MM
	844995	X	· Adjusting washer		TH = 1,10 MM
	244633	X	· Adjusting washer		TH = 1,20 MM
	844996	X	· Adjusting washer		TH = 1,25 MM
	244634	X	· Adjusting washer		TH = 1,30 MM
	847431	X	· Adjusting washer		TH = 1,35 MM
	244635	X	· Adjusting washer		TH = 1,40 MM
	847432	X	· Adjusting washer		TH = 1,45 MM
	244381	X	· Adjusting washer		TH = 1,50 MM
	244382	X	· Adjusting washer		TH = 1,60 MM
	244383	X	· Adjusting washer		TH = 1,70 MM
	244384	X	· Adjusting washer		TH = 1,80 MM
	244385	X	· Adjusting washer		TH = 1,90 MM
	244386	X	· Adjusting washer		TH = 2,00 MM
	847433	X	· Adjusting washer		TH = 2,10 MM
20	244733	6	· Sleeve		
21	18836	6	· Gasket	IK	
22	240422	12	· O-ring	IK	
23	846576	6	· Pump element		
24	846188	6	· Delivery valve		
25	239993	6	· Gasket	IK	
26	240969	6	· Spring		
27	240001	6	· Gasket	IK	
28	244636	6	· Delivery valve retai		
29	243743	12	· Washer		
30	244380	12	· Stud		
31	941908	12	· Spring washer		
32	943927	12	· Nut		
33	240011	1	· Cover		
34	956209	2	· Screw		
35	18891	2	· Lock washer		
36	240907	1	· Control rod		
37	240014	2	· Guide sleeve		
38	244008	1	· Lock pin		
39	846475	1	· Sleeve		
40	6642955	1	· Screw		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
41	947620	1	· Gasket		
42	130673	3	· Stud		
43	240971	6	· Plug		
44	240972	X	· Washer		TH = 0.2 MM
	240973	X	· Washer		TH = 0.5 MM
45	180707	1	· Plug		
46	243263	1	· Plug		
47	240017	1	· Gasket	IK	
48	845454	1	· Camshaft		
49	244406	1	· Bearing		
50	240427	2	· Screw		
51	941906	2	· Spring washer	IK	
52	240023	1	· Roller bearing		
53	864299	1	· Sealing ring	IK	
54	243299	1	· O-ring	IK	
55	240024	X	· Adjusting washer		TH = 0.10 MM
	240025	X	· Adjusting washer		TH = 0.12 MM
	240026	X	· Adjusting washer		TH = 0.14 MM
	240027	X	· Adjusting washer		TH = 0.16 MM
	240028	X	· Adjusting washer		TH = 0.18 MM
	240029	X	· Adjusting washer		TH = 0.30 MM
	240030	X	· Adjusting washer		TH = 0.50 MM
56	240021	1	· Cover		
57	956094	4	· Screw		
58	941906	4	· Spring washer	IK	
59	955806	1	· Nut		
60	955927	1	· Spring washer	IK	
61	35168	1	· Key	IK	
62	240023	1	· Roller bearing		
63	240032	1	· Ring		
64	240033	X	· Adjusting washer		TH = 1.2 MM
	240034	X	· Adjusting washer		TH = 1.5 MM
	240035	X	· Adjusting washer		TH = 1.8 MM
	240036	X	· Adjusting washer		TH = 2.0 MM
65	240947	1	· Cover		
66	1698192	1	· Gasket	IK	
67	956205	12	· Screw		
68	863370	1	· Gasket	IK	
69	940197	3	· Nut		
70	941906	3	· Spring washer	IK	
71	240811	1	· Sealing ring		
72	240812	1	· Cover		
73	240037	1	· Gasket		
74	6638096	4	· Screw		
75	240121	1	· Plug		
76	240016	1	· Protecting casing		
77	240017	1	· Gasket		
	845240	1	· Small parts kit		SEE GROUP 10A