



9117

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	846806	1	Injection pump		REPL BY 849194
	849194	1	Injection pump	02C-0500	
	3803765	1	Injection pump, exch		Exchange unit
				02C-0505	
2	847028	1	Tube		
3	847029	1	Tube		
3A	847396	1	Sleeve		
3B	959798	1	Screw		
3C	965541	1	Bracket		
3D	942336	1	Spring washer		
3E	952625	1	Clamp		
3F	955893	1	Washer		
3G	950047	1	Screw		
3H	949607	1	Spring washer		
3I	955825	1	Nut		
4	25167	3	Hollow screw		
5	969011	7	Gasket		
6	26013	2	Hollow screw		
7	947624	5	Gasket		
8	422246	1	Pipe		
9	942007	1	Hollow screw		
10	422245	1	Pressure oil line		
11	48634	1	Hollow screw		
12	947281	2	Gasket		
13	837709	1	Hollow screw		
14	18666	1	Gasket		
15	11994	1	Gasket		
16	477173	1	Pressure equalizer		
17	969011	1	Gasket		
18		1	PUMP COUPLING	02C-0325	
19	468558	1	Bracket		
20	423161	2	Guide sleeve		
21	417588	1	Guide sleeve		
22	955566	4	Screw		
23	940280	4	Spring washer		
24	940156	4	Screw		
25	190509	4	Washer		
26	845712	1	Fuel pipe		
27	25167	1	Hollow screw		
28	969011	2	Gasket		
29	847269	1	Tube		SEE GROUP 3
30	845711	1	Fuel pipe		
31	845450	2	Fuel hose		
32	956983	4	Nut		
33	956969	4	Ferrule		
34	821625	1	Anchorage		
35	821076	1	Clamp		
36	941492	1	Clamp		D = 25 MM
	952625	1	Clamp		D = 9.5 MM
37	950046	2	Screw		
38	941906	2	Spring washer		
39	955825	2	Nut		
40	243405	1	Fuel filter		
				02C-0750	
40A	862745	1	Bracket		
40B	959798	1	Screw		
40C	942336	1	Spring washer		
40D	823575	1	Spacer sleeve		
40E	862709	1	Support		
40F	940115	1	Screw		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
40G	942336	1	Spring washer		
40H	960142	1	Washer		
40I	955827	1	Nut		
40J	862708	1	Clamp		
40K	955538	2	Screw		
40L	950354	2	Lock nut		
41	845319	1	Bracket		
41A	846738	1	Spacer		
42	940134	2	Screw		
43	941909	2	Spring washer		
44	955535	2	Screw		
45	942336	2	Spring washer		
46	947191	1	Clamp		
47	35096	1	Overflow valve		
48	969011	3	Gasket		
49	16496	1	Hollow screw		
50	946729	2	Gasket		
51	74033	1	Hollow screw		
52	1545102	6	Injector		REPL BY 424530
				02C-0740	
	424530	6	Injector		
	3803243	6	Injector, exch		Exchange unit
				02C-0740	
53	469455	6	Sealing ring		
54	469797	6	Yoke		
55	1545022	6	Stud		
56	971086	6	Nut		
57	846805	1	Leak-off pipe		
58	956980	1	Nut		
59	956966	1	Ferrule		
60	1545081	1	Leak-off line		
61	74033	6	Hollow screw		INCLUDED IN FUEL INJECTOR.
62	946729	12	Gasket		INCLUDED IN FUEL INJECTOR.
63	846711	1	Delivery pipe		
64	846712	1	Delivery pipe		
65	846713	1	Delivery pipe		
66	846714	1	Delivery pipe		
67	846715	1	Delivery pipe		
68	846716	1	Delivery pipe		
69	470181	1	Clamp		2-PIPE
	470182	5	Clamp		3-PIPE
70	404279	2	Clamp		
71	956095	1	Screw		
72	941906	1	Spring washer		
73	955781	1	Nut		
74	846457	1	Reservoir		
75	846460	1	Sealing ring		
76	846459	1	Cover		
77	846458	2	Sealing ring		
78	959223	1	Screw		L = 30 MM
	959227	1	Screw		L = 50 MM
79	941907	2	Spring washer		
80	846461	2	Wing screw		
81	947620	2	Gasket		
82	951665	2	Retaining ring		
83	960630	1	Plug		
84	969011	1	Gasket		
85	25168	1	Banjo nipple		
86	957178	2	Gasket		
87	25167	1	Hollow screw		
88	848677	1	Lever		SEE GROUP 2D
89	955270	1	Screw		
90	941906	1	Spring washer		
91	847268	1	Tube		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
92	847267	1	Tube		
93	956969	5	Ferrule		
94	956983	5	Nut		
95	957123	1	T-nipple		
96	845953	12	Gasket		
97	845955	1	Tube		
98	846183	6	Hollow screw		
99	848328	1	Delivery pipe		CYL.NO.1. JACKETED FUEL PIPES
100	848329	1	Delivery pipe		CYL.NO.2. JACKETED FUEL PIPES
101	848330	1	Delivery pipe		CYL.NO.3. JACKETED FUEL PIPES
102	848331	1	Delivery pipe		CYL.NO.4. JACKETED FUEL PIPES
103	848332	1	Delivery pipe		CYL.NO.5. JACKETED FUEL PIPES
104	848333	1	Delivery pipe		CYL.NO.6. JACKETED FUEL PIPES
105	848334	2	Collecting pipe		
106	848335	1	Collecting pipe		
107	955279	1	Screw		
108	955285	1	Screw		
109	941906	2	Spring washer		
110	955781	2	Nut		