



6612

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	468351	1	Oil pump		
				02A-1250	
2	190529	2	Lock washer		
3	955538	4	Screw		
4	824156	1	Oil pump screen		
5	896682	1	Bracket		
6	414621	1	Strainer		
7	118125	1	Lock ring		
8	949658	2	O-ring		
9	955533	2	Screw		
10	941907	2	Spring washer		
11	824174	1	Tube		
12	940135	2	Screw		
13	941907	2	Spring washer		
14	468036	1	Service kit		EARLY TYPE
15	949657	1	O-ring		EARLY TYPE
16	955533	2	Screw		EARLY TYPE
17	941907	2	Spring washer		EARLY TYPE
18	466908	1	Fitting		
19	953235	2	Stud		EARLY TYPE
20	955826	2	Nut		EARLY TYPE
21	955894	4	Washer		EARLY TYPE
22	940113	2	Screw		EARLY TYPE
23	941907	2	Spring washer		EARLY TYPE
24	942385	2	Disc spring		EARLY TYPE
24A	942402	4	Flange screw		LATE TYPE
25	822586	1	Oil pan		
26		1	OIL FILTER AND INSTALLATION COMPONENTS	02A-1475 02A-1500	
27	470133	1	Gasket	IK	
28	956570	43	Screw		
29	941907	43	Spring washer		
30	822542	1	Oil dipstick		
31	846922	1	Tube		(785606)
32	822588	1	Hatch		
33	822587	2	Cover		
	822587	1	Cover		AQ140A MO-7019/XXXX. AQ120B MO-602/XXXX.
34	822589	3	Gasket	IK	
35	955535	30	Screw		
36	942336	30	Spring washer		
41	896775	1	Tube		
42	802287	1	Gasket	IK	
43	955525	2	Screw		
44	941907	2	Spring washer		
45	469465	1	Cover		
46	949658	1	O-ring		
47	468727	1	Spring		
48	470291	1	Spring		(469333)
49	471085	1	Valve		
50	469468	1	Valve seat		
51	424342	1	Sealing ring		
52	955512	2	Screw		
53	192287	2	Washer		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
54			OIL AND FUEL SUPERVISION WITH INSTALLATION COMPONENTS		SEE GROUP 3
55	843503	1	Cover		AQ140A MO-7019/XXXX. AQ120B MO-602/XXXX.
56	823185	1	Gasket		AQ140A MO-7019/XXXX. AQ120B MO-602/XXXX.
57	956569	12	Screw		AQ140A MO-7019/XXXX. AQ120B MO-602/XXXX.
58	11992	12	Gasket		AQ140A MO-7019/XXXX. AQ120B MO-602/XXXX.
59	470264	1	Delivery pipe		LATE TYPE
60	470262	1	Flange		LATE TYPE
61	470263	1	Sealing ring		LATE TYPE
62	959793	2	Screw		LATE TYPE
63	941907	2	Spring washer		LATE TYPE
64	470143	1	Bracket		LATE TYPE
65	942402	2	Flange screw		LATE TYPE
66	949786	1	Clamp		LATE TYPE
67	942402	1	Flange screw		LATE TYPE
68	955894	1	Washer		LATE TYPE
69	945467	1	Nut		LATE TYPE
70		1	SUMP PUMP AND INSTALLATION COMPONENTS	02A-1625	