



5414

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	470933	1	Injector	MARKED 788
	3803247	1	Injector, exch	Exchange unit
2	470934	1	· Nozzle	
3		1	· NOZZLE HOLDER BODY	
4	947620	2	· · Gasket	
5	240579	1	· · Hollow screw	
6	244797	X	· · Adjusting washer	TH = 1,00 MM
	244798	X	· · Adjusting washer	TH = 1,04 MM
	244788	X	· · Adjusting washer	TH = 1,08 MM
	860174	X	· · Adjusting washer	TH = 1,10 MM
	244804	X	· · Adjusting washer	TH = 1,12 MM
	244801	X	· · Adjusting washer	TH = 1,16 MM
	244799	X	· · Adjusting washer	TH = 1,20 MM
	6212417	X	· · Adjusting washer	TH = 1,22 MM
	244805	X	· · Adjusting washer	TH = 1,24 MM
	244807	X	· · Adjusting washer	TH = 1,28 MM
	859356	X	· · Adjusting washer	TH = 1,30 MM
	244789	X	· · Adjusting washer	TH = 1,32 MM
	858908	X	· · Adjusting washer	TH = 1,34 MM
	244811	X	· · Adjusting washer	TH = 1,36 MM
	846966	X	· · Adjusting washer	TH = 1,38 MM
	244800	X	· · Adjusting washer	TH = 1,40 MM
	6212393	X	· · Adjusting washer	TH = 1,42 MM
	244790	X	· · Adjusting washer	TH = 1,44 MM
	244802	X	· · Adjusting washer	TH = 1,48 MM
	859358	X	· · Adjusting washer	TH = 1,50 MM
	244791	X	· · Adjusting washer	TH = 1,52 MM
	846954	X	· · Adjusting washer	TH = 1,54 MM
	244792	X	· · Adjusting washer	TH = 1,56 MM
	858906	X	· · Adjusting washer	TH = 1,58 MM
	244793	X	· · Adjusting washer	TH = 1,60 MM
	846970	X	· · Adjusting washer	TH = 1,62 MM
	244806	X	· · Adjusting washer	TH = 1,64 MM
	244803	X	· · Adjusting washer	TH = 1,68 MM
	858905	X	· · Adjusting washer	TH = 1,70 MM
	244794	X	· · Adjusting washer	TH = 1,72 MM
	846957	X	· · Adjusting washer	TH=1.74 MM
	244812	X	· · Adjusting washer	TH = 1,76 MM
	846975	X	· · Adjusting washer	TH = 1,78 MM
	844328	X	· · Adjusting washer	TH = 1,80 MM
	6212420	X	· · Adjusting washer	TH = 1,82 MM
	846958	X	· · Adjusting washer	TH = 1,84 MM
	244808	X	· · Adjusting washer	TH = 1,86 MM
	244813	X	· · Adjusting washer	TH = 1,88 MM
	846959	X	· · Adjusting washer	TH = 1,94 MM
	244796	X	· · Adjusting washer	TH = 1,96 MM
	846980	X	· · Adjusting washer	TH = 1,98 MM
7	244820	1	· · Compression spring	
8	244821	1	· · Pressure bolt	
9	844339	2	· · Locating pin	
10	1698513	1	· · Washer	
11	244447	2	· · Pin	
12	244448	1	· · Cap nut	