



16337

REF	PART NO.	QTY	DESCRIPTION		NOTES
1		1	Reversing gear		RATIO 2.04:1
		1	Reversing gear		RATIO 2.45:1
		1	Reversing gear		RATIO 2.95:1
2	955561	8	Screw		
3	940280	8	Spring washer		
4	940134	12	Screw		
5	941909	12	Spring washer		
6	865434	1	Clutch flange	SO	
7	955751	6	Screw	SO	
8	941914	6	Spring washer		
9	950379	6	Nut		
10	965011	2	Pin	SO	
11	946834	1	Clamp		For cable, oil pressure sensor.
12	863123	1	Bracket		
13	955524	2	Screw		
14	941907	2	Spring washer		
15	819067	1	Brace		For control cable type 333.
	6853782	1	Clamp		For control cable type 443.
16	819068	1	Washer		
17	956079	2	Screw		
18	963104	2	Nut		
19	853217	1	Cube		
20	940191	1	Washer		
21	907824	1	Cotter pin		
22		X	Control cable		SEE GROUP 27
22A		1	· Nut		
23		X	Control		SEE GROUP 27
24		1	Slip valve		
25	863124	1	Bracket		When trolling valve is installed.