


TAMD122P-A



TAMD122P-A

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	866737	1	Injection pump		
	3803781	1	Injection pump, exch		Exchange unit
				3052	
2	3825154	1	• Overflow valve		
3	11996	1	Gasket		
3A	422525	1	Attaching lug		
4	74033	1	Hollow screw		
5	955566	2	Screw		
6	940280	2	Spring washer		
7	477173	1	Pressure equalizer		
8	969011	1	Gasket		
9	848677	1	Lever		
10	955270	1	Screw		
11	941906	1	Spring washer		
12	940156	4	Screw		
13	190509	4	Washer		
14	3830312	1	Fuel hose		
15	844543	1	Leak-off pipe		
16	947620	2	Gasket		
17	16496	1	Hollow screw		
18	969011	2	Gasket		
19	866784	1	Bracket		
20		2	• Guide sleeve		
21		1	• Support		
21A	479696	2	• Screw		
21B	940097	2	• Washer		
22	22753	1	Nipple		
23	866615	1	Pipe		
23A	3829244	1	Lube oil hose		SNXXXXXXXXXX/235665-(3826447)
24	837709	1	Hollow screw		
25	11994	1	Gasket		
26	942703	1	Gasket		
27	48634	1	Hollow screw		
28	947281	2	Gasket		
29	942007	1	Hollow screw		
30	947281	2	Gasket		SNXXXXXXXXXX/233031
	969011	2	Gasket		SNXXXXXXXXXX/233032-
30A	11998	1	Gasket		
31	942703	1	Gasket		
32	478964	1	Oil return pipe		SNXXXXXXXXXX/233031
	3826088	1	Oil return pipe		SNXXXXXXXXXX/233032-
33	952623	1	Clamp		SNXXXXXXXXXX/233031
34	941906	1	Spring washer		SNXXXXXXXXXX/233031
35	950045	1	Screw		SNXXXXXXXXXX/233031
36	48634	1	Hollow screw		SNXXXXXXXXXX/233031
	25167	1	Hollow screw		SNXXXXXXXXXX/233032-
37	3828983	1	Shut-off valve		
38	3828981	1	• O-ring kit		
39		1	• Valve		
39A		1	• Nut		
39B	3825240	1	• Magnet		
40	866927	1	Cable kit		
41	844576	1	• Cable union		
41A	866664	1	Connector unit		
42	977677	1	Nipple		
43	3830309	1	Fuel hose		
44	22753	1	Nipple		
45	941754	7	Nipple		
46	969011	7	Gasket		
47	973924	2	Flange screw		
48	976944	2	Washer		
49	843075	2	Sleeve		

TAMD122P-A

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
50	3826145	1	Bracket		(3825601)
51	955570	2	Screw		
52	940280	2	Spring washer		
53	1678297	2	Spacer sleeve		
54	9205207	3	Retainer		
55	479696	2	Screw		
56	942336	2	Spring washer		
57	3830311	1	Fuel hose		Feed pump - shut-off valve.
58	3830310	1	Fuel hose		Shut-off valve - injection pump.
59	3830307	1	Fuel hose		Filter housing - feed pump.
60	3830308	1	Fuel hose		Filter housing - shut-off valve.
61	8194541	2	Filter housing		(3826447)
62	471177	1	· Screw		
62A	947620	1	· Gasket		
63	968062	3	Plug		
64	3825133	2	Fuel filter		
65	940162	2	Screw		
65A	942336	2	Spring washer		
66	969299	1	Hollow screw		
67	11994	2	Gasket		
68	945417	1	Nipple		
69	944717	2	Sleeve		
70	954364	2	Fitting		
71	954356	2	Cap nut		
72	954385	1	Elbow nipple		
73	25167	1	Hollow screw		
74	945460	1	Plastic pipe		L=760mm
75	3825000	2	Nipple		ALT
76	861101	1	Banjo nipple		ALT