



23047

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3586704	1	Heat exchanger	
2	861308	1	· Cover	
3	860127	3	· Sealing strip	
4	925027	1	· O-ring	
5	964106	1	· Gasket	
6	963567	1	· Screw	
7	949918	1	· Drain cock	
8	3580719	1	Bracket	
9	838733	2	Support ring	
10	3580717	1	Bracket	
11	965185	3	Flange screw	
12	953003	1	Stud	L=130mm
	953007	1	Stud	L=150mm
13	941908	2	Spring washer	
14	971095	2	Nut	
15	860645	1	Hose	Heat exchanger-after cooler.
16	943475	1	Hose clamp	
17	860828	1	Hose	Heat exchanger-exhaust riser.
18	943475	1	Hose clamp	
19	861111	1	Hose	Thermostat housing-heat exchanger.
20	943477	1	Hose clamp	
21	861279	1	Hose	
22	943478	2	Clamp	
23	943474	1	Hose clamp	
24	942700	X	Hose	L=300mm
25	945652	1	Hose clamp	
26	861105	1	Expansion tank	For earlier version of expansion tank.
27	1674083	1	Pressure cap	
28	3582348	1	Bracket	
29	946544	3	Flange screw	
30	3580941	1	Expansion tank	For later version of expansion tank.
31	953003	1	Stud	
	953005	1	Stud	
	980835	1	Stud	
32	849845	1	Sleeve	
33	3581039	1	Bracket	TAMD31M-A, TAMD31P-A,
34	971095	3	Nut	
35	3581097	1	Hose	Heat exchanger-expansion tank-water pump.
36	943474	1	Hose clamp	
37	942700	X	Hose	L=440mm. Expansion tank-thermostat housing.
38	945652	2	Hose clamp	
39	942700	X	Hose	L=580mm. Expansion tank-Turbo.
40	1674083	1	Pressure cap	
41	967949	2	Screw	
42	952627	2	Clamp	
43	3581032	1	Spacer sleeve	
44	3285120	1	Rubber ring	
45	976944	1	Washer	
46	968999	1	Screw	