

DESCRIPTION	SEE SEC.	NOTES
Engine with Installation Components: A	19406	TMD41A, TAMD41A
Engine with Installation Components: B	19406B	TMD41A, TAMD41A
Engine with Installation Components: SOLAS	19407	TAMD41A
Engine with Installation Components: A	19408	D41A, AQAD41A, AD41A
Engine with Installation Components: B	19408B	D41A, AQAD41A, AD41A
Engine with Installation Components: C	19408C	D41A, AQAD41A, AD41A
Engine with Installation Components: A	19409	TMD41B, D41B, TAMD41B, AD41B
Engine with Installation Components: B	19409B	TMD41B, D41B, TAMD41B, AD41B
Engine with Installation Components: C	19409C	TMD41B, D41B, TAMD41B, AD41B
Engine with Installation Components: D	19409D	TMD41B, D41B, TAMD41B, AD41B
Cylinder Head: TAMD41ASOLAS	19410	TMD41A, D41A, TAMD41A, AQAD41A, AD41A
Cylinder Head	19411	TMD41B, D41B, TAMD41B, AD41B
Cylinder Block and Flywheel Cover	19412	TMD41A, TAMD41A
Cylinder Block and Flywheel Housing: SOLAS	19413	TAMD41A
Cylinder Block and Flywheel Cover	19414	TMD41B, TAMD41B
Cylinder Block and Flywheel Cover	19415	D41A, AQAD41A, AD41A
Cylinder Block and Flywheel Cover	19416	D41B, AD41B
Crankshaft and Related Parts: A	19417	TMD41A, TAMD41A
Crankshaft and Related Parts: B	19417B	TMD41A, TAMD41A
Crankshaft and Related Parts: SOLAS	19418	TAMD41A
Crankshaft and Related Parts	19419	D41A, AQAD41A, AD41A
Crankshaft and Related Parts: A	19420	TMD41B, D41B, TAMD41B, AD41B
Crankshaft and Related Parts: B	19420B	TMD41B, D41B, TAMD41B, AD41B
Crankshaft and Related Parts: C	19420C	TMD41B, D41B, TAMD41B, AD41B
Crankshaft and Related Parts: D	19420D	TMD41B, D41B, TAMD41B, AD41B
Camshaft and Valve Mechanism	19421	TMD41A, TAMD41A
Camshaft and Valve Mechanism: SOLAS	19422	TAMD41A
Camshaft and Valve Mechanism	19424	D41A, AQAD41A, AD41A
Camshaft and Valve Mechanism	19425	D41B, AD41B
Camshaft and Valve Mechanism	19423	TMD41B, TAMD41B
Timing Gear Cover and Gears	19426	TMD41A, TAMD41A
Timing Gear Cover and Gears: SOLAS	19427	TAMD41A
Timing Gear Cover and Gears	19429	D41A, AQAD41A, AD41A
Timing Gear Cover and Gears	19430	D41B, AD41B
Timing Gear Cover and Gears	19428	TMD41B, TAMD41B
Lubricating System	19431	TMD41A, D41A, TAMD41A, AQAD41A, AD41A
Lubricating System: SOLAS	19432	TAMD41A
Lubricating System	19433	TMD41B, D41B, TAMD41B, AD41B
Oil Pump: 1542210	19434	
Oil Pump: 860721	19434B	
Oil Filter and Installation Components: TAMD41A SOLAS	19435	TMD41A, D41A, TAMD41A, AQAD41A, AD41A
Oil Filter and Installation Components	19436	TMD41B, D41B, TAMD41B, AD41B
Engine Suspension: A	19437	TMD41A, TAMD41A
Engine Suspension: B	19437B	TMD41A, TAMD41A
Engine Suspension: A	19438	TMD41B, TAMD41B
Engine Suspension: B	19438B	TMD41B, TAMD41B
Engine Suspension	19439	D41A, D41B, AQAD41A, AD41A, AD41B
Engine Suspension	19440	AD41A
Engine Suspension: SOLAS	19441	