



10616

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	860953	2	Engine bracket	FRONT
2	965192	8	Flange screw	L=40mm
3	940280	8	Spring washer	
4	860952	1	Engine bracket	P, REAR
	860954	1	Engine bracket	S.B, REAR
5	940280	4	Spring washer	
	955897	2	Washer	
6	966343	3	Screw	L=35mm
	966343	1	Screw	L=35mm
	965226	2	Flange screw	L=45mm
7	876597	4	Rubber element	
8	955900	4	· Washer	
9	860950	4	· Adjuster screw	
10	955806	8	· Nut	
11	955901	4	Washer	D=34mm
	978991	4	Washer	D=40mm
11A	941913	4	Spring washer	