


230B



230B

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	HEAT EXCHANGER AND WATER FILTER WITH INSTALLATION COMPONENTS	11349	
2	855578	1	Sea water pump	11341	
3	831009	1	Cross piece		SEE GROUP 2A
4	955278	2	Hexagon screw		
5	941906	2	Spring washer		
6	855414	1	Coolant pipe		
7	857137	1	Coolant pipe		
8	946471	1	Flange screw		
9	418412	1	Sealing ring		
10	831622	2	Sealing ring		
11	831903	1	Flange		
12	946544	2	Flange screw		
13	855416	1	Coolant pipe		
14	855666	1	Bracket		
15	946440	1	Flange screw		
16	952632	1	Clamp		
17	966862	1	Flange screw		
18	955892	1	Washer		
19	418412	1	Sealing ring		
20	831622	1	Sealing ring		
21	946544	2	Flange screw		
22	180759	1	Plug		
23	3547560	1	Water pump · COMPONENTS		
24	1378491	1	Gasket		
25	3547991	1	Sealing ring		
26	968872	3	Flange screw		
27	955892	3	Washer		
28		2	Stud		
29		2	Flange nut		
30	955892	2	Washer		
31	418571	1	Plug		
32	1219915	1	Washer		
33	968871	1	Flange screw		
34		1	Flange nut		
35	855504	1	Bracket		SEE GROUP 2A
36	828035	1	· Guide bushing		SEE GROUP 2A
37		2	Hex. socket screw		SEE GROUP 2A
38	941907	2	Spring washer		SEE GROUP 2A
39	968877	1	Flange screw		SEE GROUP 2A
40	941906	1	Spring washer		SEE GROUP 2A
41	463629	1	Pulley		
42	855604	1	Washer		
43	463301	1	Washer		
44	974676	4	Flange screw		
45	966694	1	V-belt		SEE GROUP 3
46	875580	1	Thermostat kit		82°C
47	416033	1	· Sealing ring		
48	925091	1	O-ring		
49	855411	1	Thermostat housing		
50		2	Hexagon screw		
51	955892	2	Washer		
52	834352	1	Clamp		INCLUDED IN SHORTBLOCK 876141., SEE GROUP 10A
53	968885	1	Flange screw		SEE GROUP 2A
54	941907	1	Spring washer		SEE GROUP 2A
55		1	Hose		SEE GROUP 4A
56	961669	2	Hose clamp		SEE GROUP 4A
57		1	INDUCTION- AND EXHAUST MANIFOLD	11343	