



11063

## 250B

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	872241	1	Starter motor		ALSO AVAILABLE AS AN EXCHANGE PART., REPL BY 872888
	872888	1	Starter motor		ALSO AVAILABLE AS AN EXCHANGE PART.
4	946473	2	Flange screw		
5	855314	1	Nut		
7	947107	1	Flange screw		LATE TYPE
8	855798	1	Protecting sleeve		
9	855712	1	Distributor		
10	968885	1	Flange screw		
11	960141	1	Washer		
12	925065	1	O-ring		
13	875571	1	Ignition cable kit		
14		4	· IGNITION CABLE		
15		1	· IGNITION CABLE		
16	464716	2	Suppressor resistor		
17		4	Suppressor resistor		
18		4	Cable terminal		
19	241608	4	Protective sleeve		
20		4	Cable terminal		
21	875820	1	Spark plug kit		
22		2	Retainer		
23		1	Retainer		
24	965175	1	Flange screw		
25	463857	1	Retainer		
26	834462	1	Ignition coil		
27		1	Protecting casing		
28	946577	2	Lock nut		
29		1	Clamp		
30		1	Screw		
31	946440	1	Flange screw		(955523)
32	834629	1	Temperature sensor		REPL BY 872069
	872069	1	Temperature sensor		TO CONNECT TERMINAL ON TEMPERATURE 872069 USE NUT 965483 OR 955780.
33	834621	1	Nipple		
34	872063	1	Pressure sensor		(834920)
35	969011	1	Gasket		(947621)
36	960630	1	Plug		
37		1	Flange screw		
38	855331	1	Wiring harness		
39	834784	1	Resistor		
40	841178	1	Automatic fuse		
41		X	CABLE AND CABLE TERMINALS	11369	
42	841177	1	Relay		
43	855268	1	Bracket		
44	950013	2	Cross recessed screw		
45	948210	X	Cable tie		
46		1	ALTERNATOR AND INSTALLATION COMPONENTS	11360	
47	856820	1	Instrument panel		LATE TYPE
48		X	Cable trunk		L = 3000 MM
	835670	X	Cable trunk		L = 6100 MM
49	949786	1	Clamp		
51	942767	1	Toothed washer		LATE TYPE
53	856355	2	Fuse		55A
54	965570	2	Bracket		
55	941950	1	Clamp		
56	847396	1	Spacer sleeve		LATE TYPE, L = 8 MM
57	946544	1	Flange screw		
58	945407	3	Flange nut		
59	941906	1	Spring washer		
60	945444	1	Flange screw		LATE TYPE, L = 25 MM

250B

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
61	948210	1	Cable tie		