

DESCRIPTION	SEE SEC.	NOTES
Cylinder Head	5547	3.0GSP-A, 3.0GSM-A
Cylinder Head	9444	3.0GSP-B, 3.0GSP-C, 3.0GSM-B, 3.0GSM-C
Cylinder Head	9445	3.0GLP-A, 3.0GLP-B, 3.0GLM-A, 3.0GLM-B
Cylinder Block and Flywheel Housing	5548	3.0GSP-A, 3.0GSM-A
Cylinder Block and Flywheel Housing	9446	3.0GSP-B, 3.0GSP-C, 3.0GSM-B, 3.0GSM-C
Cylinder Block and Flywheel Housing	9447	3.0GLP-A, 3.0GLP-B, 3.0GLM-A, 3.0GLM-B
Crankshaft and Related Parts	5549	3.0GLP-A, 3.0GLP-B, 3.0GLM-A, 3.0GLM-B, 3.0GSP-A, 3.0GSP-B, 3.0GSP-C, 3.0GSM-A, 3.0GSM-B, 3.0GSM-C
Camshaft and Valve Train	5550	3.0GLP-A, 3.0GLP-B, 3.0GLM-A, 3.0GLM-B, 3.0GSP-A, 3.0GSP-B, 3.0GSP-C, 3.0GSM-A, 3.0GSM-B, 3.0GSM-C
Oil Pan and Oil Pump	6847	3.0GSP-A, 3.0GSP-B, 3.0GSP-C, 3.0GSM-A, 3.0GSM-B, 3.0GSM-C
Oil Pan and Oil Pump	6877	3.0GLP-A, 3.0GLP-B, 3.0GLM-A, 3.0GLM-B
Motor Mounts	5552	3.0GLP-A, 3.0GLP-B, 3.0GLM-A, 3.0GLM-B, 3.0GSP-A, 3.0GSP-B, 3.0GSP-C, 3.0GSM-A, 3.0GSM-B, 3.0GSM-C