


3.0GSMWTR, 3.0GSMWTS, 3.0GSPWTR, 3.0GSPWTS



3.0GSMWTR, 3.0GSMWTS, 3.0GSPWTR, 3.0GSPWTS

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3857853	1	Wiring harness	
2	3852233	1	Terminal, Ignition bypass	Purple
3	3852527	1	Terminal, Battery terminal	Red
4		1	Terminal, Switch	Yellow/red
5	3852233	1	Terminal, Oil pressure transmitter	Blue
6	3853565	1	Connector, Trim sender	
7	3852527	2	Terminal, Engine ground	Black
8	3852244	2	Terminal, Oil pressure switch	
9		2	Cardboard tube	
10	3852248	2	Cable sleeve	
11	3854192	1	Relay, Starter relay	
12	3852245	1	Terminal, Circuit break to alternator	Orange
13	3852245	1	Terminal, Break to 10 pin connector	
14	3852245	2	Terminal, Circuit break to circuit break	
15	3854164	2	Automatic fuse, 50 amp	
16	3852064	4	Nut	
17	3852001	4	Spring washer	
18	3852227	1	Terminal, Breaker ground	Black
19	3854244	1	Cable, Ignition coil	
20	3852084	1	Terminal	
21	3853320	1	Cardboard tube, Choke	
22		1	Cable tie	
23	3852233	1	Terminal, Water temperature transmitter	Tan
24	3852038	1	Terminal, Alternator output	Orange
25	3852130	1	Rubber cap, Terminal	
26	3852233	1	Terminal, Alternator sense	Orange
27	3852233	1	Terminal, Alternator excite	Red/purple
28	3852233	1	Terminal	
29	3852130	1	Rubber cap, Terminal	
30	3852245	1	Terminal, Alternator ground	Black
31	3852229	1	Terminal, 2 pin contact	