Longblock Cylinder Head Cylinder Block and Flywheel Housing Cylinder Block and Flywheel Housing Camshaft and Valve Train Crankshaft and Related Parts lackshaft Dil Pan and Oil Pump Dil Drain Motor Mounts	35939 10054 21464 21463 35609 22432 8769 10038 10043 5204	4.3GL-G, 4.3GL-G 4.3GL-GF 4.3GL-G 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G
Cylinder Block and Flywheel Housing Cylinder Block and Flywheel Housing Camshaft and Valve Train Crankshaft and Related Parts Jackshaft Dil Pan and Oil Pump Dil Drain	21464 21463 35609 22432 8769 10038 10043	4.3GL-GF 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G
Cylinder Block and Flywheel Housing Camshaft and Valve Train Crankshaft and Related Parts lackshaft Dil Pan and Oil Pump Dil Drain	21463 35609 22432 8769 10038 10043	4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G
Camshaft and Valve Train Crankshaft and Related Parts lackshaft Dil Pan and Oil Pump Dil Drain	35609 22432 8769 10038 10043	4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G
Camshaft and Valve Train Crankshaft and Related Parts ackshaft Dil Pan and Oil Pump Dil Drain	35609 22432 8769 10038 10043	4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G
ackshaft Dil Pan and Oil Pump Dil Drain	22432 8769 10038 10043	4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G
ackshaft vil Pan and Oil Pump vil Drain	8769 10038 10043	4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G 4.3GL-G, 4.3GL-G
il Pan and Oil Pump il Drain	10038 10043	4.3GL-G, 4.3GL-G
il Drain	10043	4.3GL-G, 4.3GL-0
lotor Mounts	5204	4.3GL-G, 4.3GL-G
Notes wounts	3204	4.502-0, 4.502-0

7745980 - 21 - 21 Upd: 2009-10-07