
4.3GLPHUB, 4.3GSPHUB, 4.3GSPHUS





4.3GLPHUB, 4.3GSPHUB, 4.3GSPHUS

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3854620		Fuel pump	
2	3850820	2		
3	3853545	1	Fitting, Fuel line to fuel pump	
4	3852064	2	Nut, Circuit breaker terminals	Engine
	3852064		Nut, Circuit breaker terminals	Tilt & trim
5	3852001		Lock washer, Circuit breaker	
6	3854123	1		GS
	3854122	1		GL
7	3854238	1		
8	3850403	1		
9 10	3852481	11	Bracket, Fuel pump & relay mounting	
11	3853620	2	Screw, Circuit breaker to bracket	
12	3853311	2		Stbd; front
13	3853557	1	Screw, Lift bracket & start leads to engine	
14	3853326		Screw, Lift bracket, fuel pump & relay assy	
15	3850861	1		
16	3851218	1	Fuel filter	
17	3853266	2		
18	3852013	1	Elbow, Inlet, fuel filter cover	
19	3853310	1	Bracket, Fuel pump, support bracket & filter	
20	3852210	1	Bracket, Relay	
21	3852208		Screw, Relay & cable assy to support bracket	Electric fuel pump
22 23	3853493 3850819	1		

4.3GLPHUB, 4.3GSPHUB, 4.3GSPHUS, 4.3GIPHUSCE

