



5362

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	831994	1	Instrument panel		
2	831993	1	· Instrument plate		
3	831466	1	· Tachometer		
4	841233	1	· Thermometer		(831475)
5	824963	1	· Starter switch		
6	831606	2	· · Key		ÅKERMAN SPEC. 867477.
7	827769	1	· Lock ring		
8	831536	1	· Nut		
9	875819	1	· Switch		(837735)
	843002	1	· · Nut		
	837726	1	· · Knob		
13	827766	2	· Lens		
14	19923	4	· Bulb		
15	819350	2	· Sleeve		
16	808175	2	· Bulb socket		
17	808174	2	· Bulb socket		
18	944540	4	· Screw		
19	831507	1	· Cable trunk		
		X	· · CABLES AND CABLE TERMINALS	030-2200	
20	827353	X	· Clamping ring		
	845071	1	· Plug		