



4152

REF	PART NO.	QTY	DESCRIPTION		NOTES
1	826827	1	Cylinder block		
2	826662	1	· Plug		
3	826663	1	· Plug		
4	826664	4	· Plug		
5	818002	4	· Plug		
6	818003	1	· Plug		
7	818047	1	· Plug		
8	818227	1	· Shaft		
9	818491	1	· · Plug		
10	818492	1	· Pin		
11	818016	2	· Gasket	IK	
12	818498	2	· Locating pin		
13	818495	2	· Locating pin		
14	826758	2	· Pin		
15	818497	4	· Locating pin		
16	818500	10	· Screw		
17	818499	10	· Washer		
18		5	· BEARING CAP		
19	818017	2	· Seal	IK	
20	818493	2	· Stud		
21	813615	1	Nipple		MO-3218827/XXXX
	947899	1	Nipple		M0 3218828/XXXX-
22	957178	1	Gasket		M0-3218827/XXXX
	957175	1	Gasket		M0 3218828/XXXX-
23	16218	1	Elbow nipple		
24	82744	1	Tap		
25	819118	1	Seal flange		
26	819119	1	Gasket	IK	
27	826600	1	Gasket		
28	826514	1	Gasket	IK	
29	955271	4	Screw		
30	941906	4	Spring washer		
31	818456	2	Inspection cover		
32	818457	2	Gasket	IK	
33	955269	10	Screw		
34	955781	2	Nut		
35	941906	12	Spring washer		
36	826925	1	Intermediate plate		
37	818240	1	Gasket	IK	
38	946514	1	Screw		
39	946515	2	Screw		
40	826845	4	Washer		
41	818273	1	Gasket	IK	
42	826736	1	Flywheel housing		
43	826765	1	Gasket	IK	SEE GROUP 4A
44	959667	1	Screw		L = 50 MM SEE GROUP 4A
	959671	2	Screw		L = 70 MM SEE GROUP 4A
45	940280	3	Spring washer		SEE GROUP 4A
46		1	LIFT EYE		SEE GROUP 4A
47	826844	1	Screw		
	946514	1	Screw		M0 3114784/XXXX-