



7395

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	HEAT EXCHANGER WITH INSTALLATION COMPONENTS	02B-0680	
2	855578	1	Sea water pump		MO-XXXX/6850
3	831622	2	Gasket	IK	02B-1150
4	831903	1	Flange		
5	956094	2	Screw		
6	831906	1	Tube		
7	834722	1	Tube		
8	418412	1	Sealing ring	IK	02B-0680
9	831622	1	Gasket	IK	
10	841913	1	Tube		
11	955271	2	Screw		
12	841906	1	Bracket		
13	955138	1	Screw		
14	960138	1	Washer		
15	952632	1	Clamp		
16	180759	1	Plug		
17	831622	1	Gasket	IK	
18	955271	2	Screw		
19		X	HOSE CLAMP		SEE GROUP 4A
20		X	HOSE		SEE GROUP 4A
21	955295	1	Screw		SEE GROUP 2A
22	941907	1	Spring washer		
23	834352	1	Clamp		
24	855566	1	Water pump		
		?	· COMPONENTS		
25	924056	2	Screw		
26	1378491	1	Gasket	IK	(1326344)
27	855604	1	Washer		
28	1336255	1	Sealing ring	IK	
29	955892	2	Washer		
30	955781	2	Nut		
31	941906	4	Spring washer		
32	955275	4	Screw		
33	463629	1	Pulley		
34	463301	1	Washer		
35	946544	4	Flange screw		
36		1	DRIVE BELT KIT		SEE GROUP 3
37	430020	1	Sealing ring	IK	02B-0680
38	831897	1	Tube		02B-0680
39	831926	1	Connection pipe		
40	963197	2	Screw		
41	955892	2	Washer		
42	875580	1	Thermostat kit	IK	82%Z9C
43	416033	1	· Sealing ring	IK	
44	955297	2	Screw		
45	941907	2	Spring washer		
46	925091	1	O-ring	IK	
47	955278	2	Screw		
48	941906	2	Spring washer		
49	831009	1	Cross piece		SEE GROUP 2A
50	855504	1	Bracket		SEE GROUP 2A
51	828035	1	· Bushing		SEE GROUP 2A
52	959230	2	Screw		SEE GROUP 2A
53	941907	2	Spring washer		SEE GROUP 2A
54	955282	1	Screw		SEE GROUP 2A
55	941906	1	Spring washer		SEE GROUP 2A
56	855598	1	Retainer		
57		1	INDUCTION- AND EXHAUST MANIFOLD	02B-1760	