



AQ145B

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	HEAT EXCHANGER WITH INSTALLATION COMPONENTS	02B-0680	
2	855578	1	Sea water pump	02B-1150	
3	831622	2	Gasket	IK	
4	831903	1	Flange		
5	956094	2	Screw		
6	831906	1	Tube		
7	855371	1	Tube		
8	418412	1	Sealing ring	IK	02B-0680
9	831622	1	Gasket	IK	
10	831907	1	Tube		
11	955271	2	Screw		
12	418412	2	Sealing ring	IK	
13	834642	1	Oil cooler		
				02B-1300	
14		1	SCREW UNION		SEE GROUP 2A
15	925255	1	O-ring	IK	
16	824589	1	Washer		
17	191701	1	Nut		
18	831908	1	Tube		
19	831622	1	Gasket	IK	
20	955271	2	Screw		
21		X	HOSE CLAMP		SEE GROUP 4A
22		X	HOSE		SEE GROUP 4A
23	955295	1	Screw		SEE GROUP 2A
24	941907	1	Spring washer		
25	834352	1	Clamp		
26	834415	1	Support ring		
27	855566	1	Water pump, PUMP COMPONENTS		
28	924056	2	Screw		
29	1378491	1	Gasket	IK	(1326344)
30	855604	1	Washer		
31	1336255	1	Sealing ring	IK	
32	955892	2	Washer		
33	955781	2	Nut		
34	941906	4	Spring washer		
35	955275	4	Screw		
36	463629	1	Pulley		
37	463301	1	Washer		
38	946544	4	Flange screw		
39		1	DRIVE BELT KIT		SEE GROUP 3
40	430020	1	Sealing ring	IK	02B-0680
41	831897	1	Tube		02B-0680
42	831926	1	Connection pipe		
43	963197	2	Screw		
44	955892	2	Washer		
45	875580	1	Thermostat kit	IK	82%Z9C
46	416033	1	Sealing ring	IK	(418361)
47	955297	2	Screw		
48	941907	2	Spring washer		
49	925091	1	O-ring	IK	
50	955278	2	Screw		
51	941906	2	Spring washer		
52	831009	1	Cross piece		SEE GROUP 2A
53	855504	1	Bracket		SEE GROUP 2A
54	828035	1	Bushing		SEE GROUP 2A
55	959230	2	Screw		SEE GROUP 2A
56	941907	2	Spring washer		SEE GROUP 2A
57	955282	1	Screw		SEE GROUP 2A
58	941906	1	Spring washer		SEE GROUP 2A
59	855598	1	Retainer		SEE GROUP 2A

AQ145B

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
60		1	INDUCTION- AND EXHAUST MANIFOLD	02B-1780	