



AQ190A

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	835606	1	Alternator		REPLACED BY 1EA 841766 ALTERNATOR, 1EA 841813 PULLEY AND 1EA 855280 INSTALLATION KIT .
				030-0400	
	841766	1	Alternator		
			COMPONENTS NOT SPEC.		
	855280	1	Mounting kit		SEE GROUP 10A
1A	841813	1	Pulley		FOR ALTERNATOR 841766
2	835605	1	Bracket		
3	835638	1	Sleeve		
3A	835639	1	Bracket		
4	959805	1	Screw		
5	941909	1	Spring washer		
6	835699	1	V-belt		
7	841249	1	Hour counter		(835677)
8	835634	1	Tensioner		
9	940115	2	Screw		
10	942336	2	Spring washer		
11	960142	1	Washer		
12	835635	1			REPL BY 841066
				030-0300	
	841066	1	Starter motor		
				030-0300	
13	940115	2	Screw		
14	942336	2	Spring washer		
15	834920	1	Oil pressure sensor		
16	835642	1	Nipple		
17	835644	1	Bracket		
18	835631	1	Temperature sensor		
19	835641	1	Regulator		
20	835597	1	Bracket		
21	950047	2	Screw		
22	835640	2	Absorber		
23	960140	2	Washer		
24	150136	2	Nut		
25	841178	1	Fuse		
26	950013	2	Screw		
27	948210	X	Strip clamp		
28	835636	1	Magnet		
29	950046	2	Screw		
30	940155	2	Lock washer		
31	955825	2	Nut		
32	955826	2	Nut		
33	955949	2	Lock washer		
34	951784	1	Nut		
35	941905	1	Spring washer		
36	835637	1	Resistor		
37	950045	1	Screw		
38	941906	1	Spring washer		
39	955825	1	Nut		
40	841225	X	Ignition cable		L = 2X590 MM
	841226	X	Ignition cable		L = 1X710 MM
	841227	X	Ignition cable		L = 2X775 MM
	841228	X	Ignition cable		L = 3X935 MM
41	875818	2	Spark plug kit		4PCS/KIT
42	1219071	2	Retainer		
43	831871	2	Clamp		
44	835904	1	Ignition cable		
45	835696	1	Ignition coil		
46	835792	1	Bracket		
47	950015	1	Screw		
48	940179	1	Nut		
49	940133	1	Screw		

AQ190A

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
50	942336	1	Spring washer		
51		1	DISTRIBUTOR AND INSTALLATION COMPONENTS	030-0200	
52	835633	1	Cable trunk		
		X	· CABLE AND TERMINALS	030-0600	
52A	835671	X	Cable trunk		L = 3000 MM. FOR INSTRUMENT PANEL 835970 AND 835971.
	835670	X	Cable trunk		L = 6000 MM. FOR INSTRUMENT PANEL 835970 AND 835971.
53	950352	1	Lock nut		
54	955844	3	Nut		
55	955556	2	Screw		SEE GROUP 2A
56	941909	2	Spring washer		
57	835970	1			REPL BY 841094
				030-0500	
	835971	1			REPL BY 841095
				030-0500	
	835972	1			REPL BY 841096
				030-0500	
	835973	1			REPL BY 841097
				030-0500	
	841094	1	Instrument panel		ALT
				030-0550	
	841095	1	Instrument panel		ALT
				030-0550	
	841096	1	Instrument panel		ALT
				030-0550	
	841097	1	Instrument panel		ALT
				030-0550	