



6980

AQ240A

| REF | PART NO. | QTY | DESCRIPTION | SEE SEC. | NOTES |
|-----|----------|-----|------------------------------|----------|------------------------|
| 1 | | 1 | CYLINDER BLOCK | 02A-0250 | |
| 2 | | 1 | CRANKSHAFT AND RELATED PARTS | | |
| | | | | 02A-0350 | |
| 3 | | 1 | LUBRICATING SYSTEM | 02A-0450 | |
| 4 | | 2 | CYLINDER HEAD | 02A-0550 | |
| 5 | 835716 | 1 | Cover | | |
| 6 | 835863 | 1 | Plug | | |
| 7 | 955526 | 2 | Screw | | |
| 7A | 941907 | 2 | Spring washer | | |
| 8 | | X | SCREW | | SEE GROUP 2B |
| 8A | | X | RESILIENT WASHER | | SEE GROUP 2B |
| 9 | 835715 | 1 | Gasket | IK | |
| 10 | 835717 | 1 | Turn signal | | |
| 11 | 835777 | 1 | Seal | IK | |
| 12 | 835903 | 1 | Gasket | IK | SEE GROUP 2B |
| 13 | 835793 | 1 | Cover plate | | |
| 14 | 835588 | 1 | Cover | | |
| 15 | 940160 | 4 | Screw | | L = 38 MM |
| | 955556 | 2 | Screw | | L = 89 MM, SEE GROUP 3 |
| 16 | 941909 | 6 | Spring washer | | |
| 17 | 953518 | 6 | Stud | | |
| 18 | 835925 | 2 | Pin | 02A-0250 | |
| 19 | 940113 | 3 | Screw | | |
| 20 | 941907 | 3 | Spring washer | | |
| 21 | 834510 | 2 | Bracket | | |
| 22 | 955552 | 4 | Screw | | |
| 23 | 955896 | 4 | Washer | | |
| 24 | 835449 | 2 | Rubber cushion | | |
| 25 | 944236 | 4 | Lock nut | | |
| 26 | 955900 | 2 | Washer | | |
| 27 | | 2 | LIFT EYE | | |
| 28 | 940116 | 2 | Screw | | |
| 29 | 941909 | 2 | Spring washer | | |