



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	832682	1	Intermediate housing		
2	897829	1	· Gear yoke		
3	814397	1	· Coupling rod		
4	897447	1	· Shaft		
5	897511	2	· Washer		
6	17253	1	· Cotter pin	IK	
7	925259	1	O-ring	IK	
8	943866	X	Adjusting washer		TH = 0,1 MM
	943867	X	Adjusting washer		TH = 0,2 MM
	943868	X	Adjusting washer		TH = 0,4 MM
9	875365	1	Suspension fork		
10	940194	1	· Nipple		
11	814388	1	· Bushing		
12	183391	1	· Needle bearing		
13	181620	2	· Sealing ring	IK	
14	941807	2	Screw		
15	814390	2	Washer		
16	941885	2	Nut		
17	897448	1	Control rod		
18	813954	1	Control fork		
19	940190	1	Nut		
20	192662	1	Clevis pin		
21	17253	2	Cotter pin		
22	814386	1	Tube		
23	941820	1	O-ring	IK	
24	897696	1	Washer		
25	941809	1	Screw		
26	941808	2	Screw		
27	851766	1	Hose connection		SEE GROUP 4A
28	814356	1	Seal	IK	
29	941813	2	Screw		
30	897644	1	Tube		
31	125017	2	O-ring	IK	
32	897457	1	Cable attachment		
33	940168	2	Screw		
34	940191	2	Washer		
35	826341	2	Bushing		
36	804312	1	Cube		
37	17276	1	Cotter pin		
38	940191	2	Washer		
39	814434	1	Reverse tilt inhibit		
40	814391	2	· Reverse tilt inhibit		
41	814389	1	· Bearing sleeve		
42	814422	2	· Spacer washer	IK	
43	852046	1	· Push rod		(814421)
44	897722	1	· Thrust sleeve		
45	814394	1	· Lock brace		
46	814395	2	· Pin		
47	832534	1	· Spring	IK	
48	814399	1	· Shaft	IK	
49	943194	1	· Washer	IK	
50	814392	1	· Spring hook	IK	LEFT
51	814419	1	· Shaft	IK	
52	814393	1	· Spring hook	IK	RIGHT.
53	943197	2	· Nut	IK	
54	814398	1	· Shaft	IK	
55	814396	1	· Spring	IK	
56	814332	2	· Spring	IK	
57	940197	1	· Nut	IK	
58	941814	2	Stud		04C-0200
59		X	CONTROL CABLE		SEE GROUP 9
	875361	1	Repair kit, REPAIR KIT ASTERN LEVER		