



| REF | PART NO. | QTY | DESCRIPTION | SEE SEC. | NOTES |
|-----|----------|-----|--|----------|------------------------------|
| 1 | 841096 | 1 | Instrument panel | | |
| 2 | 841075 | 1 | • Instrument panel | | |
| 3 | 835655 | 1 | • Instrument | | |
| 4 | 192451 | 1 | • • Bulb | | |
| 5 | 841954 | 1 | • • Bulb socket | | |
| 6 | 835654 | 1 | • Thermometer | | |
| 7 | 192451 | 1 | • • Bulb | | |
| 8 | 841954 | 1 | • • Bulb socket | | |
| 9 | 841938 | 1 | • Tachometer | | (835653). MARKEDBOSCH. |
| 10 | 192451 | 1 | • • Bulb | | |
| 11 | 841954 | 1 | • • Bulb socket | | |
| 12 | 835661 | 1 | • Ammeter | | |
| 13 | 192451 | 1 | • • Bulb | | |
| 14 | 841954 | 1 | • • Bulb socket | | |
| 16 | 192451 | 1 | • • Bulb | | |
| 17 | 841954 | 1 | • • Bulb socket | | |
| 18 | 824963 | 1 | • Starter switch | | |
| 19 | 831606 | 2 | • • Key | | REPLACED BYLATE TYPE 845108. |
| 20 | 831536 | 1 | • Nut | | |
| 21 | 827769 | 1 | • Lock ring | | |
| 22 | 841073 | 2 | • Fuse holder | | |
| 23 | 841518 | 2 | • Fuse | | |
| 24 | 875819 | 1 | • Switch | | |
| 25 | 843002 | 1 | • • Nut | | |
| 26 | 837726 | 1 | • • Knob | | |
| 27 | 835967 | 1 | • Cover plate | | |
| 28 | 835968 | 1 | • Foil | | |
| 29 | 944540 | 4 | • Screw | | |
| 30 | | X | • CABLE AND CABLE TERMINALS • TERMINALS | 030-1000 | |