

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	Instrument panel		
2	841075	1	· Instrument plate		
3		1	· Instrument		
4	192451	1	· · Bulb		
5	841954	1	· · Lamp socket		
6		1	· Thermometer		
7	192451	1	· · Bulb		
8	841954	1	· · Lamp socket		
9	841938	1	· Tachometer		Marked BOSCH., (835653)
10	192451	1	· · Bulb		
11	841954	1	· · Lamp socket		
12	835656	1	· Voltmeter		
13	192451	1	· · Bulb		
14	841954	1	· · Lamp socket		
16	192451	1	Bulb		
17	841954	1	Lamp socket		
18	824963	1	· Starter switch		
19		2	· · Key		REPLACED BY LATE TYPE 845108.
			Bulletin P-36-4-1	P-36-4-1-EN	Deleted Part No's for Keys
20		1	· Nut		
21		1	· Collar		
22	841073	2	· Fuse holder		
23	841518	2	· Fuse		
24		1	· Switch		
25	843002	1	· · Nut		
26	837726	1	· · Knob		
27	835967	1	· Cover washer		
28	835968	1	· Foil		
29	944540	4	· Screw		
30		X	· CABLE AND CABLE TERMINALS	13119	
			TERMINALS		