



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	Panel		
2	841075	1	· Instrument plate		
3		1	· Instrument		
4	192451	1	· · Bulb		
5	841954	1	· · Lamp socket		
6		1	· Thermometer		
7	192451	1	· · Bulb		
8	841954	1	· · Lamp socket		
9	841938	1	· Tachometer		REPLACED BY 1EA 841938 TACHOMETER WITH MOUNT.INSTRUCTION, 9EA TERMINALS 881493, 1EA TERMINAL 881483, 1EA PROTECTION CAP 949597, 2X120MM PURPLE CABLE 965754 AND 2X120MM BLACK CABLE 954443., (835653)
10	192451	1	· · Bulb		
11	841954	1	· · Lamp socket		
12	835656	1	· Voltmeter		
13	192451	1	· · Bulb		
14	841954	1	· · Lamp socket		
15	835967	1	· Cover washer		
16	835968	1	· Foil		
17	824963	1	· Starter switch		Marked BOSCH.
18		2	· · Key		STATE KEY CODE WHEN ORDERING
			Bulletin P-36-4-1	P-36-4-1-EN	Deleted Part No's for Keys
19		1	· Nut		
20		1	· Collar		
21		1	· Switch		
22	843002	1	· · Nut		
23	837726	1	· · Knob		
24	841073	2	· Fuse holder		
25	841518	2	· Fuse		(841076)
26	944540	4	· Screw		
27		1	· CABLE UNIT		
28		X	· · CABLES AND TERMINALS	17088	