



ENGINE WIRE HARNESS, GL/GS

REF	PART NO.	QTY	DESCRIPTION
1	3860040	1	Cable harness
2	3852527	2	Cable terminal, Engine ground
3	3852084	1	Cable terminal, Oil pressure switch
4	3853320	1	Cover, Oil pressure switch
5	3852233	1	Cable terminal, Oil pressure switch
6	3852235	1	Cable terminal, Alternator excite
7	3852245	1	Cable terminal, Alternator ground
8	3852233	1	Cable terminal, Alternator indicator light
9	3852233	1	Cable terminal, AC tap
10	3852130	2	Rubber cap
11	3852038	1	Cable terminal, Alternator output
12	3852235	1	Cable terminal, Alternator sense
13	3852084	1	Cable terminal, Water temperature switch
14	3853320	1	Cover
15	3852233	1	Cable terminal, Starter solenoid ignition terminal
16	3852235	1	Cable terminal, Starter solenoid starter terminal
17	3852527	1	Cable terminal, Starter solenoid
18	3852527	1	Cable terminal, Starter solenoid
19	3854164	1	Fuse, 50 amp
20	3852001	2	Lock washer, Circuit breaker
21	3852064	2	Nut, Circuit breaker
22	3852245	1	Cable terminal, Circuit breaker to splice
23	3854192	1	Connector, Starter relay
24	3852254	4	Cable terminal
25	3852227	1	Cable terminal, Electrical ground bracket
26	3852084	1	Cable terminal, Choke
27	3853320	1	Cover, Choke
28	3852229	1	Cable terminal, Receptacle
29	3852233	1	Cable terminal, Water temperature transmitter
30	3852210	1	Bracket
31	3850403	1	Relay
32	3852247	1	Cable terminal
33	3852246	3	Cable terminal
34	3853679	2	Cable terminal
35	916127	1	Fuel pump
36	916453	1	Fuel pump
37	3852233	1	Cable terminal, Ignition coil
38	3852233	1	Cable terminal, Ignition coil distributor terminal
39	3852257	1	Cable terminal, Plug
40	3853565	1	Connector, Trim sender
41	3852229	1	Cable terminal, Trim sender
42	979686	1	Fuse, 40 amp
43	969197	1	Fuse, 7.5 amp
44	3860455	2	Fuse holder