



5011

MB2

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1	Bracket		
2		1	Coil		
3		2	Screw		
4		1	Lighting coil		
5		2	Flange screw		
6	3578367	1	Screw		
7		1	Bracket		
8		1	Clamp		
9		1	Flywheel		(3579107) SEE GROUP 2A
10		1	lcm		
10A		1	· Protecting cap		
11		2	Screw		
12		1	Clamp		
13		1	Impulse sensor		
14		2	Locating pin		
15		1	Plate		
16		2	Screw		
17		2	Washer		
18		1	Washer		
19		1	Wheel		
20		1	Pressure monitor		
21		1	· Washer		
22		1	· Screw		
23		1	Temperature sensor		(855140)
24		1	Spacer		
25		1	Brace		
26	955269	1	Hexagon screw		
27		1	Ignition coil		
28		1	· Nut		
29		1	· Washer		
30		2	· Cover		
31		1	· Clamp		
32		1	Screw		
33		1	Screw		
34		1	Clamp		
35		1	Spacer tube		
36		2	Nut		
37		1	Cable trunk		
38		1	Housing		
39		2	Sleeve		
40		1	Retainer		
41		1	Washer		
42		1	Screw		
43		2	Nut		
44		X	CABLES AND TERMINALS	13538	
45	3579075	2	Spark plug		
46		1	Rectifier		
47		1	· Fuse		5A
48		1	Instrument panel	13537	
49		1	Clamp		
50		3	Flange screw		
51		2	Guide sleeve		