

GR71815

Upd: 22 NOV 2005

1       3852746       1       Hose, Thermostat hsg to manifold         2       3853780       2       Clamp, Hose to elbow, exhaust manifold         3       3857391       1       Hose, Thermostat hsg to water pump         4       3852098       2       Clamp, Hose, thermostat hsg to water pump         5       3858669       1       Thermostat housing         6       3853799       1       Thermostat         7       3856537       1       O-ring, Thermostat         8       3852096       1       Gasket, Therm hsg to cylinder head       Part of engine g         9       3852029       1       Sender, Water temperature       9         8       7       3852029       1       Sender, Water temperature, dual station       9         10       3853266       1       Screw, Therm. hsg to engine       1         11       3857822       1       Fitting, Straight       1         12       3850268       1       V-belt, Water pump       1         13       3857794       1       Sea water pump       1         14       3850323       1       Hose, Gimbal hsg to water pump       Manual steering         16       3857823       1					
2         3853780         2         Clamp, Hose to elbow, exhaust manifold           3         3857391         1         Hose, Thermostat hsg to water pump           4         3852098         2         Clamp, Hose, thermostat hsg to water pump           5         3858699         1         Thermostat housing           6         3853799         1         Thermostat           7         3856537         1         Oring, Thermostat           8         3852096         1         Gasket, Therm hsg to cylinder head         Part of engine g           9         3852092         1         Sender, Water temperature         Part of engine g           10         3853266         1         Sender, Water temperature, dual station         Sender, Water temperature, dual station           10         3853268         1         Screw, Therm. hsg to engine         Sender, Water pump           11         3857822         1         Fitting, Straight         Fitting, Straight           12         3850268         1         V-belt, Water pump         Manual steering           14         3850422         1         Clamp, Hose, water pump inlet         Manual steering           15         3852331         1         Hose, Thermostat hsg to exhaust elbow		PART NO.	QTY	DESCRIPTION	NOTES
3   3857391   1   Hose, Thermostat hag to water pump					
4       3852098       2       Clamp, Hose, thermostat hosy to water pump         5       3858869       1       Thermostat housing         6       3853799       1       Description of the pump         7       3856537       1       O-ring, Thermostat         8       3852096       1       Gasket, Therm hsg to cylinder head       Part of engine general parts of the					
5         3858869         1         Thermostat           6         3853799         1         Thermostat           7         3856537         1         O-ring, Thermostat           8         3852096         1         Gasket, Therm hsg to cylinder head         Part of engine of en					
6         3853799         1         Thermostat           7         3856537         1         O-ring, Thermostat           8         3852096         1         Gasket, Therm hsg to cylinder head         Part of engine g           9         3852029         1         Sender, Water temperature         872068         1         Sender, Water temperature, dual station           10         3853266         1         Screw, Therm. hsg to engine         1           11         3857822         1         Fitting, Straight         1           12         3850268         1         V-belt, Water pump         1           13         3857794         1         Sea water pump         Manual steering           14         3850422         1         Clamp, Hose, water pump inlet         1           15         3852331         1         Hose, Gimbal hsg to water pump         Manual steering           16         3857823         1         Hose, Thermostat hsg to exhaust elbow         1/2-in. I.D.           17         3857821         1         Fitting, Water to high rise elbow         1/2-in. I.D. hose           18         3853792         2         Clamp, Hose, therm. hsg           20         3853155         2				Clamp, Hose, thermostat hsg to water pump	
7         3856537         1         O-ring, Thermostat         Part of engine g           8         3852096         1         Gasket, Therm hsg to cylinder head         Part of engine g           9         3852029         1         Sender, Water temperature         Sender, Water temperature, dual station           10         3853266         1         Screw, Therm. hsg to engine         Fitting, Straight           11         3857822         1         Fitting, Straight         Fitting, Straight           12         3850268         1         V-belt, Water pump         Manual steering           13         3857794         1         Sea water pump         Manual steering           14         3850422         1         Clamp, Hose, water pump inlet         Manual steering           15         3852331         1         Hose, Gimbal hsg to water pump         Manual steering           16         3857823         1         Hose, Thermostat hsg to exhaust elbow         1/2-in. I.D.           17         3857821         1         Fitting, Water be high rise elbow         1/2-in. I.D. hose           18         3853794         2         Clamp, Hose, therm. hsg         Part of engine g           20         3853155         2         Screw, Water pump b					
8       3852096       1       Gasket, Therm hsg to cylinder head       Part of engine of a state of engine of engine of a state of engine of engine of a state of engine	-				
9 3852029 1 Sender, Water temperature 872068 1 Sender, Water temperature, dual station 10 3853266 1 Screw, Therm. hsg to engine 11 3857822 1 Fitting, Straight 12 3850268 1 V-belt, Water pump 13 3857794 1 Sea water pump 14 3850422 1 Clamp, Hose, water pump inlet 15 3852331 1 Hose, Gimbal hsg to water pump 16 3857823 1 Hose, Thermostat hsg to exhaust elbow 1/2-in. I.D. 17 3857821 1 Fitting, Water to high rise elbow 1/2-in. I.D. hose 18 3853794 2 Clamp, Hose, therm. hsg 19 3857223 1 Bracket, Water pump to engine 20 3853155 2 Screw, Water pump to bracket 21 3852162 2 Washer, Screw, water pump to bracket 22 3853342 1 Gasket, Water pump to bracket 23 3854017 1 Water pump 24 3853167 2 Screw, Water pump 25 3852063 2 Screw, Water pump 26 3853401 1 Pulley, Water pump 27 3853390 4 Screw, Water pump 28 3851592 1 Hose, Thermostat hsg to manifold 29 3852538 1 Elbow, Water hose to exhaust manifold 30 3853780 2 Clamp, Hose, therm. hsg to manifold				O-ring, Thermostat	
872068					Part of engine gasket kit
10   3853266   1   Screw, Therm. hsg to engine	9			Sender, Water temperature	
11       3857822       1       Fitting, Straight         12       3850268       1       V-belt, Water pump         13       3857794       1       Sea water pump         14       3850422       1       Clamp, Hose, water pump inlet         15       3852331       1       Hose, Gimbal hsg to water pump       Manual steering         16       3857823       1       Hose, Thermostat hsg to exhaust elbow       1/2-in. I.D.         17       3857821       1       Fitting, Water to high rise elbow       1/2-in. I.D. hose         18       3853794       2       Clamp, Hose, therm. hsg         19       3857223       1       Bracket, Water pump to engine         20       3853155       2       Screw, Water pump to bracket         21       3853405       2       Washer, Screw, water pump to bracket         22       3853421       1       Gasket, Water pump         24       3853167       2       Screw, Water pump         25       3852063       2       Screw, Water pump         26       3853390       4       Screw, Water pump pulley to hub         28       3851592       1       Hose, Thermostat hsg to manifold         29       3852538<					
12       3850268       1       V-belt, Water pump         13       3857794       1       Sea water pump         14       3850422       1       Clamp, Hose, water pump inlet         15       3852331       1       Hose, Gimbal hsg to water pump       Manual steering         16       3857823       1       Hose, Thermostat hsg to exhaust elbow       1/2-in. I.D.         17       3857821       1       Fitting, Water to high rise elbow       1/2-in. I.D. hose         18       3853794       2       Clamp, Hose, therm. hsg         19       3857223       1       Bracket, Water pump to engine         20       3853155       2       Screw, Water pump to bracket         21       3852162       2       Washer, Screw, water pump to bracket         22       385342       1       Gasket, Water pump       Part of engine					
13       3857794       1       Sea water pump         14       3850422       1       Clamp, Hose, water pump inlet         15       3852331       1       Hose, Gimbal hsg to water pump       Manual steering         16       3857823       1       Hose, Thermostat hsg to exhaust elbow       1/2-in. I.D.         17       3857821       1       Fitting, Water to high rise elbow       1/2-in. I.D. hose         18       3853794       2       Clamp, Hose, therm. hsg         19       3857223       1       Bracket, Water pump to engine         20       3853155       2       Screw, Water pump to bracket         21       3852162       2       Washer, Screw, water pump to bracket         22       3853342       1       Gasket, Water pump         24       3853167       2       Screw, Water pump         25       3852063       2       Screw, Water pump         26       3852401       1       Pulley, Water pump         27       3853390       4       Screw, Water pump pulley to hub         28       3851592       1       Hose, Thermostat hsg to manifold         29       3852538       1       Elbow, Water hose to exhaust manifold         30 <td></td> <td></td> <td></td> <td>Fitting, Straight</td> <td></td>				Fitting, Straight	
14       3850422       1       Clamp, Hose, water pump inlet         15       3852331       1       Hose, Gimbal hsg to water pump       Manual steering         16       3857823       1       Hose, Thermostat hsg to exhaust elbow       1/2-in. I.D.         17       3857821       1       Fitting, Water to high rise elbow       1/2-in. I.D. hose         18       3853794       2       Clamp, Hose, therm. hsg         19       3857223       1       Bracket, Water pump to engine         20       3853155       2       Screw, Water pump to bracket         21       3852162       2       Washer, Screw, water pump to bracket         22       3853342       1       Gasket, Water pump       Part of engine of engi					
15       3852331       1       Hose, Gimbal hsg to water pump       Manual steering         16       3857823       1       Hose, Thermostat hsg to exhaust elbow       1/2-in. I.D.         17       3857821       1       Fitting, Water to high rise elbow       1/2-in. I.D. hose         18       3853794       2       Clamp, Hose, therm. hsg         19       3857223       1       Bracket, Water pump to engine         20       3853155       2       Screw, Water pump to bracket         21       3852162       2       Washer, Screw, water pump to bracket         22       3853342       1       Gasket, Water pump         24       3853167       2       Screw, Water pump         24       3853167       2       Screw, Water pump         25       3852063       2       Screw, Water pump         26       3852401       1       Pulley, Water pump pulley to hub         27       3853390       4       Screw, Water pump pulley to hub         28       3851592       1       Hose, Thermostat hsg to manifold         29       3852538       1       Elbow, Water hose to exhaust manifold         30       3853780       2       Clamp, Hose, therm. hsg to manifold			1		
16       3857823       1       Hose, Thermostat hsg to exhaust elbow       1/2-in. I.D.         17       3857821       1       Fitting, Water to high rise elbow       1/2-in. I.D. hose         18       3853794       2       Clamp, Hose, therm. hsg         19       3857223       1       Bracket, Water pump to engine         20       3853155       2       Screw, Water pump to bracket         21       3852162       2       Washer, Screw, water pump to bracket         22       3853342       1       Gasket, Water pump         24       3853167       2       Screw, Water pump         25       3852063       2       Screw, Water pump         26       3852401       1       Pulley, Water pump pulley to hub         28       3851592       1       Hose, Thermostat hsg to manifold         29       3852538       1       Elbow, Water hose to exhaust manifold         30       3853780       2       Clamp, Hose, therm. hsg to manifold			1		
17       3857821       1       Fitting, Water to high rise elbow       1/2-in. I.D. hose         18       3853794       2       Clamp, Hose, therm. hsg         19       3857223       1       Bracket, Water pump to engine         20       3853155       2       Screw, Water pump to bracket         21       3852162       2       Washer, Screw, water pump to bracket         22       3853342       1       Gasket, Water pump       Part of engine o	15	3852331	1		Manual steering
18       3853794       2       Clamp, Hose, therm. hsg         19       3857223       1       Bracket, Water pump to engine         20       3853155       2       Screw, Water pump to bracket         21       3852162       2       Washer, Screw, water pump to bracket         22       3853342       1       Gasket, Water pump       Part of engine	16	3857823			
19       3857223       1       Bracket, Water pump to engine         20       3853155       2       Screw, Water pump to bracket         21       3852162       2       Washer, Screw, water pump to bracket         22       3853342       1       Gasket, Water pump       Part of engine of eng	17	3857821	1	Fitting, Water to high rise elbow	1/2-in. I.D. hose
19       3857223       1       Bracket, Water pump to engine         20       3853155       2       Screw, Water pump to bracket         21       3852162       2       Washer, Screw, water pump to bracket         22       3853342       1       Gasket, Water pump       Part of engine of eng		3853794		Clamp, Hose, therm. hsg	
20       3853155       2       Screw, Water pump to bracket         21       3852162       2       Washer, Screw, water pump to bracket         22       3853342       1       Gasket, Water pump       Part of engine of engin		3857223	1	Bracket, Water pump to engine	
21       3852162       2       Washer, Screw, water pump to bracket         22       3853342       1       Gasket, Water pump       Part of engine			2	Screw, Water pump to bracket	
22       3853342       1       Gasket, Water pump       Part of engine of engin					
23       3854017       1       Water pump         24       3853167       2       Screw, Water pump         25       3852063       2       Screw, Water pump         26       3852401       1       Pulley, Water pump         27       3853390       4       Screw, Water pump pulley to hub         28       3851592       1       Hose, Thermostat hsg to manifold         29       3852538       1       Elbow, Water hose to exhaust manifold         30       3853780       2       Clamp, Hose, therm. hsg to manifold					Part of engine gasket kit
24       3853167       2       Screw, Water pump         25       3852063       2       Screw, Water pump         26       3852401       1       Pulley, Water pump         27       3853390       4       Screw, Water pump pulley to hub         28       3851592       1       Hose, Thermostat hsg to manifold         29       3852538       1       Elbow, Water hose to exhaust manifold         30       3853780       2       Clamp, Hose, therm. hsg to manifold					<u> </u>
25       3852063       2       Screw, Water pump         26       3852401       1       Pulley, Water pump         27       3853390       4       Screw, Water pump pulley to hub         28       3851592       1       Hose, Thermostat hsg to manifold         29       3852538       1       Elbow, Water hose to exhaust manifold         30       3853780       2       Clamp, Hose, therm. hsg to manifold					
26       3852401       1       Pulley, Water pump         27       3853390       4       Screw, Water pump pulley to hub         28       3851592       1       Hose, Thermostat hsg to manifold         29       3852538       1       Elbow, Water hose to exhaust manifold         30       3853780       2       Clamp, Hose, therm. hsg to manifold			2	Screw, Water pump	
2738533904Screw, Water pump pulley to hub2838515921Hose, Thermostat hsg to manifold2938525381Elbow, Water hose to exhaust manifold3038537802Clamp, Hose, therm. hsg to manifold				Pulley, Water pump	
28 3851592 1 Hose, Thermostat hsg to manifold 29 3852538 1 Elbow, Water hose to exhaust manifold 30 3853780 2 Clamp, Hose, therm. hsg to manifold				Screw, Water pump pulley to hub	
29 3852538 1 Elbow, Water hose to exhaust manifold 30 3853780 2 Clamp, Hose, therm. hsg to manifold					
30 3853780 2 Clamp, Hose, therm. hsg to manifold				Elbow. Water hose to exhaust manifold	
31 3858855 1 Fitting					
			1	Fitting	