



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		90315A 2	KEY SWITCH ASSEMBLY (2')	-	QUANTITIES: (90315A2,A15,A20)	
-		90315A15	KEY SWITCH ASSEMBLY (15')	-	QUANTITIES: (90315A2,A15,A20)	
-		90315A20	KEY SWITCH ASSEMBLY (20')	-	QUANTITIES: (90315A2,A15,A20)	
-		14885A 2	KEY SWITCH ASSEMBLY (2')	-	QUANTITIES: (90315A2,A15,A20)	
-		14885A15	KEY SWITCH ASSEMBLY (15')	-	QUANTITIES: (90315A2,A15,A20)	
-		14885A20	KEY SWITCH ASSEMBLY (20')	-	QUANTITIES: (90315A2,A15,A20)	
-	84	17925A 2	KEY SWITCH ASSEMBLY (2')	-	QUANTITIES: (90315A2,A15,A20)	
-	84	17925A15	KEY SWITCH ASSEMBLY (15')	-	QUANTITIES: (90315A2,A15,A20)	
-	84	17925A20	KEY SWITCH ASSEMBLY (20')	-	QUANTITIES: (90315A2,A15,A20)	
-	84	816626A 2	KEY SWITCH ASSEMBLY (2')	-	QUANTITIES: (90315A2,A15,A20)	
-	84	816626A15	KEY SWITCH ASSEMBLY (15')	-	QUANTITIES: (90315A2,A15,A20)	
-	84	816626A20	KEY SWITCH ASSEMBLY (20')	-	QUANTITIES: (90315A2,A15,A20)	
-	84	816626A25	KEY SWITCH ASSEMBLY (25')	-	QUANTITIES: (90315A2,A15,A20)	
1		90468A 1	COVER	-	QUANTITIES: (90315A2,A15,A20)	
3		76424	BRACKET	-	QUANTITIES: (90315A2,A15,A20)	
4	16	55422	STUD	-	QUANTITIES: (90315A2,A15,A20)	
5	12	24676	WASHER	-	QUANTITIES: (90315A2,A15,A20)	
6	11	68219	NUT	-	QUANTITIES: (90315A2,A15,A20)	
7		76723	RETAINER	-	QUANTITIES: (90315A2,A15,A20)	
8		89976	PLATE	-	QUANTITIES: (90315A2,A15,A20)	
8		816479	PLATE	-	QUANTITIES: (90315A2,A15,A20)	
9	87	88107	SWITCH	-	QUANTITIES: (90315A2,A15,A20)	
10	11	93543	NUT	-	QUANTITIES: (90315A2,A15,A20)	
11	38	90311	INSERT	-	QUANTITIES: (90315A2,A15,A20)	
12	10	24231	SCREW	-	QUANTITIES: (90315A2,A15,A20)	
13	11	27164	NUT	-	QUANTITIES: (90315A2,A15,A20)	
14	85	62359 4	SLEEVE	-	QUANTITIES: (90315A2,A15,A20)	
15		68878A 6	ALARM HORN	-	QUANTITIES: (90315A2,A15,A20)	
16		68879	COVER	-	QUANTITIES: (90315A2,A15,A20)	
17	23	812711 1	SPACER (3/8")	-	QUANTITIES: (90315A2,A15,A20)	
17	23	812711	SPACER (1/4")	-	QUANTITIES: (90315A2,A15,A20)	
18		816492A 1	ALARM	-	QUANTITIES: (90315A2,A15,A20)	
-		89491 1	SWITCH KEY 1A	AR		4
-		89491 2	SWITCH KEY 1B	AR		4
-		89491 3	SWITCH KEY 1C	AR,AR.		4
-		89491 4	SWITCH KEY 1D	AR,AR.		4
-		89491 5	SWITCH KEY 1E	AR,AR.		4
-		89491 6	SWITCH KEY 1F	AR,AR.		4
-		89491 7	SWITCH KEY 2A	AR,AR.		4
-		89491 8	SWITCH KEY 2B	AR,AR.		4