

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		78408A	5 TRIM CONTROL PANEL ASSEMB	1		
1	87	78406	TOGGLE SWITCH	1		
2		55738A	1 SWITCH ASSEMBLY, PUSH BU	1		
3		11099A	1 BOOT ASSEMBLY	1		
4	84	87394A20	HARNES ASSEMBLY	1		
5	88	79091	FUSE (20 AMP)	1		
6	88	69358A	1 FUSE HOLDER ASSEMBLY	1		
7		79101T	STRAP	1		
8	84	69174A	2 CABLE ASSEMBLY (RED)	2		
9		49440	LOCK NUT	1		
10		NLA	STUD	2		3
11	12	24676	WASHER	2		
12	11	27164	NUT	2		
13		55691	COVER	1		
14	10	62568	SCREW	2		

