



| Parts List |       |        |                                |     |         |          |
|------------|-------|--------|--------------------------------|-----|---------|----------|
| Ref        | Class | Part   | Description                    | Qty | Comment | Footnote |
| -          | 87    | 63917A | 3 SWITCH ASSEMBLY, COMP. - ST. | 1   |         |          |
| -          |       | 76426A | 4 SWITCH ASSEMBLY, COMP.       | .1  |         |          |
| 1          |       | 55642A | 6 PANEL ASSEMBLY, IGNITION ST. | 2   |         |          |
| 1A         |       | 76426  | PANEL, IGNITION START-STOP     | 1   |         |          |
| 2          |       | 55738A | 1 SWITCH ASSEMBLY, PUSH BUT    | 1   |         |          |
| 2          |       | 55738A | 1 SWITCH ASSEMBLY, PUSH BUT    | .2  |         |          |
| 3          | 87    | 65296  | SWITCH ASSEMBLY, PUSH BUT      | 1   |         |          |
| 4          | 23    | 63886  | BUSHING, PUSH BUTTON SWIT      | 1   |         |          |
| 5          |       | 55641  | RETAINER, PUSH BUTTON SWIT     | 1   |         |          |
| 5A         |       | 77642  | RETAINER, PUSH BUTTON SWIT     | 1   |         |          |
| 6          | 10    | 62568  | SCREW, SWITCH RETAINER TO      | 4   |         |          |
| 6          | 10    | 62568  | SCREW, SWITCH RETAINER TO      | .3  |         |          |
| 7          | 16    | 55422  | STUD, SWITCH PANEL TO DASH     | 4   |         |          |
| 7          | 16    | 55422  | STUD, SWITCH PANEL TO DASH     | .2  |         |          |
| 8          | 12    | 20878  | WASHER, SWITCH PANEL STUD      | 4   |         |          |
| 8          | 12    | 24676  | WASHER, SWITCH PANEL STUD      | .2  |         |          |
| 9          | 11    | 27164  | NUT, SWITCH PANEL STUD         | 4   |         |          |
| 9          | 11    | 45076  | NUT, SWITCH PANEL STUD         | .2  |         |          |
| 10         | 84    | 63889  | HARNESS, SWITCH PANEL - STA    | 1   |         |          |
| 10         | 84    | 63888  | HARNESS, SWITCH PANEL - C/D    | 1   |         |          |
| 10         | 84    | 78999A | 1 HARNESS, SWITCH PANEL (4 WI  | .1  |         |          |
| 11         | 84    | 63594A | 1 LEAD WIRE, C/D IGNITION (WHI | 1   |         |          |
| 12         |       | 55993  | 3 LEAD WIRE, C/D IGNITION (WHI | 1   |         |          |
| 13         |       | 75021  | .1 STRAP, MOUNTING - PANEL TO  | .1  |         |          |