

				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
-		36447A	1 INSTRUMENT PANEL ASSEMBLY	1		
1		36439	PANEL, INSTRUMENT	1		
2		37008	OIL PRESSURE GAUGE ASSEM	1		
3	12	33110	WASHER, FIBER - OIL PRESSU	2		
4	13	26996	LOCKWASHER, OIL PRESSURE	2		
5	11	20645	NUT, OIL PRESSURE GAUGE T	2		
6		34333	STOP SWITCH ASSEMBLY	1		
7		36437	INDICATOR LIGHT ASSEMBLY,	1		
8		36432	LIGHT BULB, INDICATOR LIGH	1		
9		36435	RESISTOR ASSEMBLY	1		
10		32870	JUMPER WIRE, IGNITION SWIT	1		
11		52337	SWITCH, IGNITION - INSTRUM	1		
12		34093	PLATE,IGNITION SWITCH	1		
13		32861	BEZEL,IGNITION SWITCH TO II	1		
14	37	32851	DECAL,INSTRUMENT PANEL	1		
15	37	36552	DECAL,INSTRUMENTPANEL - G	1		
16	37	36551	DECAL,INSTRUMENT PANEL -	1		
17	19	32863	BUTTON, PLUG - INSTRUMENT	1		
18	10	32866	SCREW, INSTRUMENT PANEL	4		
19	12	33110	WASHER, FIBER - INSTRUMEN	8		
20	12	20878	WASHER, INSTRUMENT PANE	4		
21	11	20190	NUT, INSTRUMENT PANEL SCI	4		
22		46900	TACHOMETER ASSEMBLY	1		
23		49917A	SOCKET ASSEMBLY, LIGHT BU	1		
24		32878	LIGHT BULB, TACHOMETER SC	1		
25	13	26996	LOCKWASHER, TACHOMETER	2		
26	11	20645	NUT, TACHOMETER TERMINAI	2		
27		32865	SOCKET, LIGHT BULB - INSTR	2		
28		32878	LIGHT BULB, INSTRUMENT PA	2		
29		34631	AMMETER GAUGE ASSEMBLY	1		
30	12	33110	WASHER, FIBER - AMMETER G	2		
31	13	26996	LOCKWASHER, AMMETER GAL	2		
32	11	20645	NUT, AMMETER GAUGE TERM	2		
33		34321	WATER TEMPERATURE GAUG	1		
34	12	33110	WASHER, FIBER - WATER TEM	2		
35	13	26996	LOCKWASHER, WATER TEMPE	2		
36	11	20645	NUT, WATER TEMPERATURE	2		
37		34333	HEATER SWITCH ASSEMBLY	1		
38		36429	JUMPER WIRE, HEATER SWIT	1		
39		36427	JUMPER WIRE, STOP SWITCH	1		

